Original		Substitut	
	Power		Power
EJECT	Eject	ZOOM	Eject
TV/DISC	Tv/Disc	SEARCH TV/R	TV/R
ATV/DTV	ATV/DTV	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
AD	AD	SHIFT + AD SUBT	Shift + Subt
INPUT	Input	TIMER AV	AV
MUTE	Mute	MUTE	Mute

Original		Substitut	
QUICK	Quick	FAV PRE-CH	Pre Ch
P	P+	CH +	Ch +
P	P-	CH -	Ch -
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
POPUP MENU	Pop Up Menu	E-MANUAL D.MENU	D. Menu
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
DISC MENU GUIDE	Guide/Disc	GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
SET UP MENU	Menu/Set Up	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
PAUSE	Pause		Pause

Original		Substitut	
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
SKIP	I<< Skip		I<<
REV	<< Rev		<<
FF	>> FF		>>
(SLOW) SKIP	Skip >>I (Slow		>>I
PROGRAM	Red/Program	A	Red
DIGEST	Green/Digest	B	Green
ZOOM	Yellow/Zoom	C	Yellow
BOOK MARK	Blue/Book Mark	D	Blue
	[≡?]	APP MEDIA	Media
	[≡+]	PICTURE FORMAT	Format
	[≡♦]	ECO 3D	3D
	[≡o]/[≡x]	PROG SLEEP	Sleep
	[▼]	SETTINGS OPT	Options
TEXT	Text	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Substitut	
CD I/II	O)I/II	SOUND DUAL	Dual
	[≡i]/[i+]	DISPLAY INFO	Info
ANGLE	Angle	REC MODE	Rec