Mandis shop

Yamaha VP590400

Original		Replacement	
POWER	Power		Power
PLAY/CUT	Play/Cut Phono	MEDIA DISPLAY	Display / Media
PHONO	Phono	DVD 2	2
SKIP	I<< Skip CD	PRESET-	I<< / Preset-
SKIP	>>I Skip CD	PRESET+	>>I / Preset+
PLAY	Play CD	SLOW	Play / Slow
CD	CD	CD-STB 3	3
SEARCH	<< Search CD	TUNE-	<< / Tune-
SEARCH	>> Search CD	TUNE+	>> / Tune+
PAUSE/STOP	Pause/Stop CD	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STOP	Pause/Stop CD	HOLD	Stop / Hold
DISC SKIP	Disc Skip CD	SURROUND	Eject / Surround
PRESET	Preset - Tuner	SHIFT + PRESET-	Shift + I<< / Preset-
PRESET	Preset - Tuner	CH PAGE	CH- / Page-
PRESET +	Deck A/B Tape	HOME MENU	Menu / Home
A/B/C/D/E	A/B/C/D/E Tuner	LIST SMART	Smart / List
TUNER	Tuner	TUNER 6	6

Original		Replacement	
DIR A	Dir A Tape		Up
DECK A/B	Preset + Tuner	CH PAGE +	CH+ / Page+
DECK A/B	Preset + Tuner	SHIFT + PRESET+	Shift + >>I / Preset+
DIR B	Dir B Tape		Down
TAPE 1	Tape 1	VIDEO 4	4
	<< Tape		Left
PLAY	Play Tape	OK	OK
	>> Tape		Right
TAPE 2	Tape 2	TAPE 5	5
REC/PAUSE	Rec/Pause Tape	RETURN BACK	Back / Return
STOP	Stop Tape	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REC MUTE	Rec Mute Tape	DIMMER MUTE	Mute / Dimmer
PRESET SKIP	EQ Preset Skip	LANG I/II AUDIO	Audio / Lang I/II
ON/FLAT	EQ On/Flat	EQ SUBTITLE	Subtitle / EQ
AUX	AUX	AUX-HDD 7	7
–	Vol-	VOL –	Vol-
+	Vol+	+ VOL	Vol+

https://mandos-a-distancia.es/en/Yamaha/1038654-65376-replacement-remote-control-for-Yamaha-VP59040-VP590400.html