Original		Replacement	
POWER	Power		Power
EJECT OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
POWER	Power Tv	SHIFT +	Shift + Power
AV	AV Tv	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
PR	PR+ Tv	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	PR- Tv	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOL	Vol+ Tv	+ VOL	Vol+
0	0	HDMI-SAT 0	0

Original		Replacement	
MUTE	Mute Tv	DIMMER MUTE	Mute / Dimmer
	Vol- Tv	VOL −	Vol-
BACKWARD	<<	TUNE-	<< / Tune-
FORWARD	>>	TUNE+	>> / Tune+
SKIP	I<<	PRESET-	I<< / Preset-
SKIP	>>I	PRESET+	>>I / Preset+
PAUSE/STEP	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
DISPLAY CLK/CNT	Display	MEDIA DISPLAY	Display / Media
PR / TRK	Up		Up
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
	Down		Down

Original		Replacement	
RETURN	Return	RETURN BACK	Back / Return
AUDIO	O))/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	[...]/Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Camera/Angle	ANGLE INFO	Info / Angle
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
TITLE	Title	TITLE SOUND	Sound / Title
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B LP	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RANDOM CM SKIP	Random	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement

Original		Replacement	
POWER	Power		Power
EJECT OPEN/CLOSE	Eject	SURROUND	Eject / Surround
AV	AV	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/VCR	Tv/VCR	PROGRAM TV/RADIO	TV/Radio /
0	0	HDMI-SAT 0	0
BACKWARD	<<	TUNE-	<< / Tune-
FORWARD	>>	TUNE+	>> / Tune+
PAUSE/STEP	Pause/Step	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement	
	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
DISPLAY CLK/CNT	CLK/CNT	MEDIA DISPLAY	Display / Media
PR / TRK	Up		Up
PR / TRK	PR/TRK+	CH PAGE +	CH+ / Page+
SETUP	i	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	PR/TRK-	CH PAGE −	CH- / Page-
	Down		Down
AUDIO	O)))/Audio	LANG I/II AUDIO	Audio / Lang I/II
REC/ITR	Rec/ITR	REC MODE	Rec / Rec Mode
LOCK	Lock	RETURN BACK	Back / Return
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original	Replacement	Original	Replacement
A-B LP LP	FORMAT PICTURE Picture / Format		
RANDOM CM SKIP CM Skip	LIST SMART Smart / List		