Mandis shop

Denon RC-1083

Original	Replacement	Original	Replacement
On/Off	Power	Favorite	Pre Ch
Sleep	Sleep	Mute	Mute
Internet Radio	1	Preset Radio	Menu
Radio	2	Return	Back
iPod	3	Up	Up
PC Music	4	Down	Down
CD	5	+	Right
USB/AUX	6	-	Left
Play	Play	Enter	Ok
Pause	Pause	Dimmer	Media
Stop	Stop		
>>I	>>I		
I <<	I <<		
Play Mode	Guide		
Display	Info		
Vol +	Vol +		
Vol -	Vol -		

https://mandis-distance.com/10557-1930-replacement-remote-control-for-Denon-RC-1083-0039912108.htm