Original		Replacement	
STANDBY CHARGE	Standby	Power	
OPEN/CLOSE	Open/Close	ZOOM	Eject
KEY LOCK	Key Lock	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
DIGEST	Digest	HOME SMART	Smart
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
AUDIO MODE	Audio Mode	SOUND DUAL	Dual

Original		Replacement	
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
TITLE MENU	Title Menu	TOP MENU MENU	Menu
SUBTITLE MENU	Subtitle Menu	AD SUBT	Subt
AUDIO MENU	Audio Menu	APP MEDIA	Media
PBC	PBC	C	Yellow
3D	3D	ECO 3D	3D
ANGLE	Angle	SEARCH TV/R	TV/R
DISPLAY	Display	DISPLAY INFO	Info
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
BOOKMARK	Bookmark	PICTURE FORMAT	Format
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R

Original		Replacement		Original	Replacement
PROGRAM	Program	PROG SLEEP	Sleep		
SLOW/F	Slow/F	-/-- GUIDE	Guide		
SLOW/R	Slow/R	FAV PRE-CH	Pre Ch		
▶	Play	PLAY MODE ▶	Play		
■	Stop	■	Stop		
▶▶I	>>I	>>I	>>I		
I◀◀	I <<	I<<	I <<		
▶▶	>>	>>	>>		
◀◀	<<	<<	<<		
PAUSE/ STEP	Pause/Step	II	Pause		
RANDOM	Random	D	Blue		
MUTE	Mute	MUTE	Mute		
REPEAT	Repeat	REPEAT TEXT	Text		
A - B	A-B	DISC NAV LIST	List		