Original		Replacement	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
P.MODE	P.Mode	OPT-TOOLS SETUP	Setup / OPT /
S.MODE	S.Mode	TITLE SOUND	Sound / Title
	Home	SHIFT + HOME MENU	Shift + Menu /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
Q.VIEW	Q.View	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI - SAT 0	0
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	
VOL	Vol-	VOL −	Vol-
VOL	Vol+	+ VOL	Vol+
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+
AUDIO I/II	I/II/Audio	LANG I/II AUDIO	Audio / Lang I/II
P	P-	CH PAGE −	CH- / Page-
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
3D WORLD	3D World	MEDIA DISPLAY	Display / Media
INFO	Info	ANGLE INFO	Info / Angle
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
SCREEN	Screen	FORMAT PICTURE	Picture / Format
CH.LIST	CH List	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Left		Left
OK	OK	OK	OK

Original		Replacement		Original		Replacement	
	Right		Right				
BACK	Back	RETURN BACK	Back / Return				
	Down		Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	<<	TUNE-	<< / Tune-				
	Green	APP REPEAT	Green / APP / Repeat				
	>>	TUNE+	>> / Tune+				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	I<<	PRESET-	I<< / Preset-				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
	>>I	PRESET+	>>I / Preset+				
	Text	GOTO TEXT	Text / Goto				
	Play	SLOW	Play / Slow				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Stop	HOLD	Stop / Hold				
	Rec	REC MODE	Rec / Rec Mode				