Original	Replacement	Original	Replacement
Source Power	SHIFT + Shift + Power	3	3
On/Standby	Power	4	4
Subwoofer Level -	CH- / Page-	5	5
Subwoofer Level +	CH+ / Page+	6	6
Audio RDS	AV / Input / RDS	Play	Play / Slow
DVD/CD	SHIFT + Shift + 2	Stop	Stop / Hold
DVD/CD	SHIFT + Shift + 3	7	7
FM/AM	SHIFT + Shift + 6	8	8
AUX	SHIFT + Shift + 7	9	9
Subtilte/PTY	Subtitle / EQ	DVS/Stereo	Sound / Title
Angle/CT	SHIFT + Shift + Info / Angle	Clear	Exit / Cancel / Clear
Zoom/RT	Zoom / Size	0	0
iPod	SHIFT + Shift + 5	+10	Guide / EPG / -/--
Net/USB	SHIFT + Shift + 8	Still/Pause	Pause / Step / Freeze
Display	Display / Media	Call	Picture / Format
1	1	Program	TV/Radio /
2	2	Random	Blue / Prime Video / Random

Original	Replacement	Original	Replacement
Repeat	Green / APP / Repeat	Up	Up
Vol +	Vol +	Left	Left
HDMI	Shift + 0	Push/ Enter	OK
Status	Info / Angle	Right	Right
Tone	Audio / Lang I/II	Tool	Setup / OPT /
I <</ Channel -	I << / Preset -	Down	Down
>>I / Channel +	>>I / Preset +	Return	Back / Return
Vol -	Vol -	Home	Smart / List
Sleep	Sleep / Timer	Home	Shift + Menu /
<</ Tuning-	<< / Tune-		
>>/ Tuning+	>> / Tune+		
Mute	Mute / Dimmer		
Top Menu	D. Menu / Top		
Menu/ Guide	Menu / Home		
Surround	Eject / Surround		
Surround	Text / Goto		
Memo	Fav / Marker / PC		

Original	Replacement	Original	Replacement
Source Power	SHIFT + Power		
On/ Standby	Power		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Vol +	Vol +		
Channel -	CH- / Page-		
Channel +	CH+ / Page+		
Vol -	Vol -		
Mute	Mute / Dimmer		

Original		Replacement		Original	Replacement
SOURCE POWER	Source Power	SHIFT +	Shift + Power		
ON / STANDBY	On/ Standby		Power		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
	Vol +	VOL +	Vol +		
	Channel -	CH PAGE −	CH- / Page-		
	Channel +	CH PAGE +	CH+ / Page+		
	Vol -	VOL −	Vol -		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		

Original		Replacement		Original		Replacement
SOURCE POWER	Source Power	SHIFT +	Shift + Power			
ON / STANDBY	On/ Standby		Power			
	Play	SLOW	Play / Slow			
	Stop	HOLD	Stop / Hold			
STILL / PAUSE	Still / Pause	STEP - FREEZE	Pause / Step / Freeze			
	Vol +	VOL +	Vol +			
	Channel -	CH PAGE −	CH- / Page-			
	Channel +	CH PAGE +	CH+ / Page+			
	Vol -	VOL −	Vol -			
	<<	TUNE-	<< / Tune-			
	>>	TUNE+	>> / Tune+			
MUTE	Mute	DIMMER MUTE	Mute / Dimmer			