Original		Replacement	
	Power		Power
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
AV LINK/ TV ASPECT	Tv Aspect/AV Link	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
-	Tracking/V-Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol+	+ VOL	Vol+
INPUT SELECT AV	AV/Input Select	RDS AV INPUT	AV / Input / RDS

Original		Replacement	
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
−	Vol-	VOL −	Vol-
LIBRARY/SEARCH	Library/Search	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
ShowView	ShowView	ANGLE INFO	Info / Angle
STILL ALBUM	Still Album	LIST SMART	Smart / List
REPLAY	Replay	RETURN BACK	Back / Return
II/▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
▶	Play	SLOW ▶	Play / Slow
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
◀	Left	◀	Left
<<	<<	TUNE- <<	<< / Tune-

Original		Replacement	
OK	OK	OK	OK
Right	Right	Right	Right
>>	>>	TUNE+	>> / Tune+
Down	Down	Down	Down
Stop	Stop	HOLD	Stop / Hold
Prog./Check Up	Prog./Check Up	SHIFT +	Shift + Up
Date+	Date+	SHIFT +	Shift + Right
On+	On+	SHIFT + VOL	Shift + Vol+
Off+	Off+	SHIFT + CH PAGE	Shift + CH+ /
Prog./Check Down	Prog./Check Down	SHIFT +	Shift + Down
DATE	Date-	SHIFT +	Shift + Left
ON	On-	SHIFT + VOL	Shift + Vol-
OFF TIMER	Off-	SHIFT + CH PAGE	Shift + CH- /
PROG./CHECK	Prog.Check	PROGRAM TV/RADIO	TV/Radio /
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SP/LP/EP	SP/LP/EP	OPT-TOOLS SETUP	Setup / OPT /
TIMER	Timer	TIMER SLEEP	Sleep / Timer

Original		Replacement	
I-TIMER	I-Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
OSD/DISPLAY	OSD/Display	MEDIA DISPLAY	Display / Media
RESET	Reset	APP REPEAT	Green / APP / Repeat

Original		Replacement	
	Power		Power
AV LINK/ TV ASPECT	Tv Aspect/AV Link	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CKING/V-LOCK +	Tracking/V.Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
-	Tracking/V.Lock-	CH PAGE –	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol+	+ VOL	Vol+
INPUT SELECT AV	AV/Input Select	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0

Original		Replacement	
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
–	Vol-	VOL –	Vol-
	Prog./Check Up		Up
	Red	NETFLIX SEARCH	Red / Netflix / Search
+ DATE	Green	APP REPEAT	Green / APP / Repeat
+ DATE	Date+		Right
+ ON	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+ ON	On+	SHIFT + + VOL	Shift + Vol+
+ OFF	Blue	Prime Video RANDOM	Blue / Prime Video / Random
+ OFF	Off+	SHIFT + + CH PAGE	Shift + CH+ /
PROG./CHECK	Prog./Check Down		Down
DATE –	Date-		Left
ON –	On-	SHIFT + VOL –	Shift + Vol-
OFF – TIMER	Off-	SHIFT + CH PAGE –	Shift + CH- /