Mandis shop

LG AKB75675311

Original		Replacement	
	Power		Power
	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
	Search	MEDIA DISPLAY	Display / Media
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
	☼	TOP MENU D.MENU	D.Menu / Top
	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0

Original		Replacement	
•••	···	PC FAV MARKER	Fav / Marker / PC
	Vol+	+ VOL	Vol+
QUICK ACCESS AD	AD	LANG I/II AUDIO	Audio / Lang I/II
	CH+	+ CH PAGE	CH+ / Page+
	Vol-	VOL −	Vol-
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	CH-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	Home	HOME MENU	Menu / Home
prime video	Prime Video	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
BACK	Back	RETURN BACK	Back / Return
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
	OK	OK	OK
	Right		Right

Original		Replacement		Original	Replacement
TEXT	Text	GOTO TEXT	Text / Goto		
▽	Down	▼	Down		
T.OPT	T.Opt	OPT-TOOLS SETUP	Setup / OPT /		
MOVIES	Movies	FORMAT PICTURE	Picture / Format		
REC	Rec	REC MODE ●	Rec / Rec Mode		
□	Stop	HOLD ■	Stop / Hold		
◁◁	<<	TUNE- ◁◁	<< / Tune-		
▷	Play	SLOW ▶	Play / Slow		
‖	Pause	STEP-FREEZE ‖	Pause / Step / Freeze		
▷▷	>>	TUNE+ ▷▷	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●●	Green	APP REPEAT	Green / APP / Repeat		
●●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●●●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		