| Original | | Replacement | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| OPEN/CLOSE | Open / Close | ZOOM | Eject |
| ANGLE | Angle | PICTURE FORMAT | Format |
| DISPLAY /INFO | Display / Info | DISPLAY INFO | Info |
| Q-PLAY TV/RADIO | Q-Play / TV/Radio | SEARCH TV/R | TV/R |
| Q-PLAY TV/RADIO | Q-Play / TV/Radio | SHIFT + PLAY MODE | Shift + Play |
| P/N /EPG | P/N / EPG | -/-- GUIDE | Guide |
| SEARCH /TTX | Search / TTX | REPEAT TEXT | Text |
| SEARCH /TTX | Search / TTX | SHIFT + SEARCH TV/R | Shift + TV/R |
| PBC /LIST | PBC / List | DISC NAV LIST | List |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |

| Original | | Replacement | |
|---|---|---|---|
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| RANDOM | Random | HOME SMART | Smart |
| AUDIO | Audio | SOUND DUAL | Dual |
| VOL+ | Vol+ | + VOL | Vol + |
| VOL- | Vol- | VOL − | Vol - |
| STOP | Stop | ■ | Stop |
| PLAY | Play | PLAY MODE ▶ | Play |
| PAUSE | Pause | ❚❚ | Pause |
| PREV | Red / Prev | A | Red |
| PREV | Red / Prev | ⏮ | I<< |
| NEXT | Green / Next | B | Green |
| NEXT | Green / Next | ⏭ | >>I |
| REW | Yellow / REW | C | Yellow |
| REW | Yellow / REW | « | << |

| Original | | Replacement | |
|---|---|---|---|
| FF | Blue / FF | D | Blue |
| FF | Blue / FF | >> | >> |
| SETUP | Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| CH+ | Up / CH+ | | Up |
| CH+ | Up / CH+ | + CH | Ch + |
| | Down / CH- | | Down |
| | Down / CH- | CH − | Ch - |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| TITLE /Pg Up | Title / Pg Up | SHIFT + + CH | Shift + Ch + |
| TITLE /Pg Up | Title / Pg Up | APP MEDIA | Media |
| MENU /Pg Dn | Menu / Pg Dn | TOP MENU MENU | Menu |
| MENU /Pg Dn | Menu / Pg Dn | SHIFT + CH − | Shift + Ch - |
| ZOOM PVR | Zoom / PVR | SHIFT + ZOOM | Shift + Eject |
| REPEAT | Rec / Repeat | REC MODE | Rec |

| Original | | Replacement | |
|---|---|---|---|
| REPEAT | Rec / Repeat | SHIFT + REPEAT TEXT | Shift + Text |
| A-B FAV | A-B / FAV | FAV PRE-CH | Pre Ch |
| SLOW EXIT | Exit / Slow | CLEAR EXIT | Exit |
| VIDEO | Video | SHIFT + TIMER AV | Shift + AV |
| SLOW EXIT | Exit / Slow | SHIFT + >> | Shift + >> |
| STEP | Step | SHIFT + II | Shift + Pause |
| DVD/DVB | DVD / DVB | TIMER AV | AV |
| MUTE | Mute | MUTE | Mute |