| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| DISPLAY | Display | DISPLAY INFO | Info |
| BD/DVD | Input BD/DVD | SHIFT + 1 | Shift + 1 |
| VCR/DVR | Input VCR/DVR | SHIFT + 2 | Shift + 2 |
| CBL/SAT | Input CBL/SAT | SHIFT + 3 | Shift + 3 |
| GAME | Input Game | SHIFT + 4 | Shift + 4 |
| AUX | Input AUX | SHIFT + 5 | Shift + 5 |
| TUNER | Input Tuner | SHIFT + 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + 7 | Shift + 7 |
| PORT | Input Port | SHIFT + 8 | Shift + 8 |
| MUTING | Muting | MUTE | Mute |
| CH DISC + | CH + | CH + | Ch + |
| ALBUM − | CH - | CH − | Ch - |
| VOL + | Vol + | VOL + | Vol + |
| VOL − | Vol - | VOL − | Vol - |
| GUIDE/TOP MENU | Guide / Top Menu | E-MANUAL D.MENU | D. Menu |
| GUIDE/TOP MENU | Guide / Top Menu | SHIFT + TOP MENU | Shift + Menu |

| Original | | Replacement | |
|---|---|---|---|
| GUIDE/TOP MENU | Guide / Top Menu | -/-- GUIDE | Guide |
| PREV CH/MENU | Prev CH / Menu | TOP MENU MENU | Menu |
| PREV CH/MENU | Prev CH / Menu | FAV PRE-CH | Pre Ch |
| | Up | | Up |
| PLAYLIST /CATEGORY | Left / Playlist/Category | | Left |
| ENTER | Enter | OK | Ok |
| PLAYLIST /CATEGORY | Right / Playlist/Category | | Right |
| | Down | | Down |
| SETUP | Setup | SETTINGS OPT | Options |
| AUDIO | Audio | SOUND DUAL | Dual |
| RETURN | Return | RETURN BACK | Back |
| | I<< | | I<< |
| | >>I | | >>I |
| | << | | << |
| | Play | PLAY MODE | Play |
| | >> | | >> |
| | Pause / Play Reverse | | Pause |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | | Stop |
| MOVIE/TV SEARCH | Movie/TV / Searc | A | Red |
| MOVIE/TV SEARCH | Movie/TV / Searc | SEARCH TV/R | TV/R |
| MUSIC REPEAT | Music / Repeat | B | Green |
| MUSIC REPEAT | Music / Repeat | REPEAT TEXT | Text |
| GAME RANDOM | Game / Random | C | Yellow |
| STEREO PLAY MODE | Stereo / Play | D | Blue |
| STEREO PLAY MODE | Stereo / Play | SHIFT + PLAY MODE | Shift + Play |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| 11 0 | 0 | 0 | 0 |
| --/--10 +10 D.TUN DIMMER | +10 / Dimmer | SHIFT + -/-- GUIDE | Shift + Guide |
| --/--10 +10 D.TUN DIMMER | D.Tun Tuner | APP MEDIA | Media |
| 12 CLR SLEEP | Clear / Sleep | CLEAR EXIT | Exit |
| 12 CLR SLEEP | Clear / Sleep | PROG SLEEP | Sleep |

| Original | | Replacement | |
|---|---|---|---|
| On/Standby | | Power | |
| Input BD/DVD | | Shift + 1 | |
| Input VCR/DVR | | Shift + 2 | |
| Input CBL/SAT | | Shift + 3 | |
| Input Game | | Shift + 4 | |
| Input AUX | | Shift + 5 | |
| Input Tuner | | Shift + 6 | |
| Input TV/CD | | Shift + 7 | |
| Input Port | | Shift + 8 | |
| Muting | | Mute | |
| Vol + | | Vol + | |
| Vol - | | Vol - | |
| On/Standby | | Shift + Power | |
| Display BD/DVD | | Info | |
| Guide / Top Menu BD/DVD | | Shift + Menu | |
| Guide / Top Menu BD/DVD | | D. Menu | |
| Guide / Top Menu BD/DVD | | Guide | |

| Original | | Replacement | |
|---|---|---|---|
| Prev CH / Menu BD/DVD | | Menu | |
| Prev CH / Menu BD/DVD | | Pre Ch | |
| Up BD/DVD | | Up | |
| Left / Playlist/Categor | | Left | |
| Enter BD/DVD | | Ok | |
| Right / Playlist/Categor | | Right | |
| Down BD/DVD | | Down | |
| Setup BD/DVD | | Options | |
| Audio BD/DVD | | Dual | |
| Return BD/DVD | | Back | |
| I<< BD/DVD | | I<< | |
| >>I BD/DVD | | >>I | |
| << BD/DVD | | << | |
| Play BD/DVD | | Play | |
| >> BD/DVD | | >> | |
| Pause BD/DVD | | Pause | |
| Stop BD/DVD | | Stop | |

| Original | | Replacement | |
|---|---|---|---|
| MOVIE/TV SEARCH | Movie/TV / Search BD/DVD | A | Red |
| MOVIE/TV SEARCH | Movie/TV / Search BD/DVD | SEARCH TV/R | TV/R |
| MUSIC REPEAT | Music / Repeat BD/DVD | B | Green |
| MUSIC REPEAT | Music / Repeat BD/DVD | REPEAT TEXT | Text |
| GAME RANDOM | Game / Random BD/DVD | C | Yellow |
| STEREO PLAY MODE | Stereo / Play Mode BD/DVD | D | Blue |
| STEREO PLAY MODE | Stereo / Play Mode BD/DVD | SHIFT + PLAY MODE | Shift + Play |
| 1 | 1 BD/DVD | 1 | 1 |
| 2 | 2 BD/DVD | 2 | 2 |
| 3 | 3 BD/DVD | 3 | 3 |
| 4 | 4 BD/DVD | 4 | 4 |
| 5 | 5 BD/DVD | 5 | 5 |
| 6 | 6 BD/DVD | 6 | 6 |
| 7 | 7 BD/DVD | 7 | 7 |
| 8 | 8 BD/DVD | 8 | 8 |
| 9 | 9 BD/DVD | 9 | 9 |
| 11 0 | 0 BD/DVD | 0 | 0 |

| Original | | Replacement | |
|---|---|---|---|
| --/---10 +10 D.TUN DIMMER | +10 / Dimmer | SHIFT + -/-- GUIDE | Shift + Guide |
| 12 CLR SLEEP | CLR / Sleep | CLEAR EXIT | Exit |
| 12 CLR SLEEP | CLR / Sleep | PROG SLEEP | Sleep |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| BD/DVD | Input BD/DVD | SHIFT + 1 | Shift + 1 |
| VCR/DVR | Input VCR/DVR | SHIFT + 2 | Shift + 2 |
| CBL/SAT | Input CBL/SAT | SHIFT + 3 | Shift + 3 |
| GAME | Input Game | SHIFT + 4 | Shift + 4 |
| AUX | Input Aux | SHIFT + 5 | Shift + 5 |
| TUNER | Input Tuner | SHIFT + 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + 7 | Shift + 7 |
| PORT | Input Port | SHIFT + 8 | Shift + 8 |
| MUTING | Muting | MUTE | Mute |
| VOL | Vol + | VOL + | Vol + |
| VOL | Vol - | VOL - | Vol - |
| ON/STANDBY | On / Standby | SHIFT + | Shift + Power |
| DISPLAY | Display TV/CD | DISPLAY INFO | Info |
| CH DISC | Disc + / Album + TV/CD | CH + | Ch + |
| ALBUM | Disc - / Album - TV/CD | CH - | Ch - |
| | Up TV/CD | | Up |

| Original | | Replacement | |
|---|---|---|---|
| PLAYLIST /CATEGORY | Left / Playlist/Category | | Left |
| ENTER | Enter TV/CD | OK | Ok |
| PLAYLIST /CATEGORY | Right / Playlist/Category | | Right |
| | Down TV/CD | | Down |
| SETUP | Setup TV/CD | SETTINGS OPT | Options |
| AUDIO | Audio TV/CD | SOUND DUAL | Dual |
| RETURN | Return TV/CD | RETURN BACK | Back |
| | I<< TV/CD | | I<< |
| | >>I TV/CD | | >>I |
| | << TV/CD | | << |
| | >> TV/CD | | >> |
| | Play TV/CD | PLAY MODE | Play |
| | Pause TV/CD | | Pause |
| | Stop TV/CD | | Stop |
| MOVIE/TV SEARCH | Movie/TV / Search TV/CD | A | Red |
| MOVIE/TV SEARCH | Movie/TV / Search TV/CD | SEARCH TV/R | TV/R |
| MUSIC REPEAT | Music / Repeat TV/CD | B | Green |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| MUSIC REPEAT | Music / Repeat TV/CD | REPEAT TEXT | Text | | |
| GAME RANDOM | Game / Random | C | Yellow | | |
| STEREO PLAY MODE | Stereo / Play Mode TV/CD | D | Blue | | |
| STEREO PLAY MODE | Stereo / Play Mode TV/CD | SHIFT + PLAY MODE | Shift + Play | | |
| 1 | 1 TV/CD | 1 | 1 | | |
| 2 | 2 TV/CD | 2 | 2 | | |
| 3 | 3 TV/CD | 3 | 3 | | |
| 4 | 4 TV/CD | 4 | 4 | | |
| 5 | 5 TV/CD | 5 | 5 | | |
| 6 | 6 TV/CD | 6 | 6 | | |
| 7 | 7 TV/CD | 7 | 7 | | |
| 8 | 8 TV/CD | 8 | 8 | | |
| 9 | 9 TV/CD | 9 | 9 | | |
| 11 0 | 0 TV/CD | 0 | 0 | | |
| 10 +10 D.TUN DIMMER | +10 / Dimmer | -/-- GUIDE | Guide | | |
| 12 CLR SLEEP | CLR / Sleep TV/C | CLEAR EXIT | Exit | | |
| 12 CLR SLEEP | CLR / Sleep TV/C | PROG SLEEP | Sleep | | |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| BD/DVD | Input BD/DVD | SHIFT + 1 | Shift + 1 |
| VCR/DVR | Input VCR/DVR | SHIFT + 2 | Shift + 2 |
| CBL/SAT | Input CBL/SAT | SHIFT + 3 | Shift + 3 |
| GAME | Input Game | SHIFT + 4 | Shift + 4 |
| AUX | Input AUX | SHIFT + 5 | Shift + 5 |
| TUNER | Input Tuner | SHIFT + 6 | Shift + 6 |
| TV/CD | Input TV/CD | SHIFT + 7 | Shift + 7 |
| PORT | Input Port | SHIFT + 8 | Shift + 8 |
| MUTING | Muting | MUTE | Mute |
| VOL | Vol + | VOL | Vol + |
| VOL | Vol - | VOL | Vol - |
| ON/STANDBY | On / Standby Por | SHIFT + | Shift + Power |
| DISPLAY | Display Port | DISPLAY INFO | Info |
| CH DISC | CH + Port | CH | Ch + |
| ALBUM | CH - Port | CH | Ch - |
| | Up Port | | Up |

| Original | | Replacement | |
|---|---|---|---|
| PLAYLIST /CATEGORY | Left / Playlist/Categor | | Left |
| ENTER | Enter Port | OK | Ok |
| PLAYLIST /CATEGORY | Right / Playlist/Categor | | Right |
| | Down Port | | Down |
| SETUP | Setup Port | SETTINGS OPT | Options |
| RETURN | Return Port | RETURN BACK | Back |
| | I<< Port | | I<< |
| | >>I Port | | >>I |
| | << Port | | << |
| | Play Port | PLAY MODE | Play |
| | >> Port | | >> |
| | Pause / Play Reverse Port | | Pause |
| | Stop Port | | Stop |
| MOVIE/TV SEARCH | Movie/TV / Searc Port | A | Red |
| MOVIE/TV SEARCH | Movie/TV / Searc Port | SEARCH TV/R | TV/R |
| MUSIC REPEAT | Music / Repeat | B | Green |
| MUSIC REPEAT | Music / Repeat | REPEAT TEXT | Text |

Port

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| GAME RANDOM | Game / Random | C | Yellow | | |
| STEREO PLAY MODE | Stereo / Play Mode Port | D | Blue | | |
| STEREO PLAY MODE | Stereo / Play Mode Port | SHIFT + PLAY MODE | Shift + Play | | |
| 1 | 1 Port | 1 | 1 | | |
| 2 | 2 Port | 2 | 2 | | |
| 3 | 3 Port | 3 | 3 | | |
| 4 | 4 Port | 4 | 4 | | |
| 5 | 5 Port | 5 | 5 | | |
| 6 | 6 Port | 6 | 6 | | |
| 7 | 7 Port | 7 | 7 | | |
| 8 | 8 Port | 8 | 8 | | |
| 9 | 9 Port | 9 | 9 | | |
| 0 11 | 0 Port | 0 | 0 | | |
| --/--10 +10 D.TUN DIMMER | +10 / Dimmer | -/-- GUIDE | Guide | | |
| 12 CLR SLEEP | CLR / Sleep Port | CLEAR EXIT | Exit | | |
| 12 CLR SLEEP | CLR / Sleep Port | PROG SLEEP | Sleep | | |