Original	Replacement
ON	Power
Standby	Shift + Power
Display	Display / Media
BD / DVD	Shift + 2
VCR / DVR	Shift + 4
CBL / SAT	Shift + 0
GAME	Shift + 5
PC	Shift + Fav / Marker / PC
AUX	Shift + 7
TUNER	Shift + 6
TV/CD	Shift + 3
TV/CD	Shift + 1
PHONO	Shift + Guide / EPG / -/--
PORT	Fav / Marker / PC
NET	Shift + 9
USB	Shift + 8
Muting	Mute / Dimmer

Original	Replacement
CH+	CH+ / Page+
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
SP Layout	D. Menu / Top
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Home	Smart / List
I <<	I << / Preset-
>>I	>>I / Preset+
<<	<< / Tune-

Original	Replacement	Original	Replacement
Play	SLOW Play / Slow	+10 D.TUN DIMMER Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
>>	TUNE+ >> / Tune+	+10 D.TUN DIMMER D. TUN	GOTO TEXT Text / Goto
Pause / Play Rev	STEP-FREEZE Pause / Step / Freeze	0	HDMI - SAT 0
Stop	HOLD Stop / Hold	CLR SLEEP Sleep	TIMER SLEEP Sleep / Timer
MOVIE/TV SEARCH Movie / TV	NETFLIX SEARCH Red / Netflix / Search		
MUSIC REPEAT Music	APP REPEAT Green / APP / Repeat		
GAME RANDOM Game	YouTube REPEAT A-B Yellow / YouTube / Repeat		
THX PLAY MODE Thx	Prime Video RANDOM Blue / Prime Video / Random		
1	TV 1		
2	DVD 2		
3	CD - STB 3		
4	VIDEO 4		
5	TAPE 5		
6	TUNER 6		
7	AUX - HDD 7		
8	USB 8		
9	BLUETOOTH 9		

Original	Replacement
On	Power
Standby	Shift + Power
Display	Display / Media
BD / DVD	Shift + 2
VCR / DVR	Shift + 4
CBL / SAT	Shift + 0
GAME	Shift + 5
PC	Shift + Fav / Marker / PC
AUX	Shift + 7
TUNER	Shift + 6
TV/CD	Shift + 3
TV/CD	Shift + 1
PHONO	Shift + Guide / EPG / -/--
PORT	Fav / Marker / PC
NET	Shift + 9
USB	Shift + 8
Muting	Mute / Dimmer

Original	Replacement
CH+ / Album+	CH+ / Page+
Vol +	Vol +
CH- / Album	CH- / Page-
Vol -	Vol -
Top Menu	D. Menu / Top
Up	Up
Menu	Menu / Home
Left / Playlist	Left
Enter	OK
Right / Playlist	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Home	Smart / List
I <<	I << / Preset-
>>I	>>I / Preset+
<<	<< / Tune-

Original	Replacement	Original	Replacement
Play	SLOW Play / Slow	--/--- +10	GUIDE EPG Guide / EPG / -/--
>>	TUNE+ >> / Tune+	0	HDMI - SAT 0
Pause / Play Rev	STEP - FREEZE Pause / Step / Freeze	Sleep	TIMER SLEEP Sleep / Timer
Stop	HOLD Stop / Hold	CLR	CLEAR EXIT CANCEL Exit / Cancel / Clear
MOVIE/TV SEARCH Search	NETFLIX SEARCH Red / Netflix / Search		
MUSIC REPEAT Repeat	APP REPEAT Green / APP / Repeat		
GAME RANDOM Random	Prime Video RANDOM Blue / Prime Video / Random		
THX PLAY MODE Play Mode	YouTube REPEAT A-B Yellow / YouTube / Repeat		
1	TV 1		
2	DVD 2		
3	CD - STB 3		
4	VIDEO 4		
5	TAPE 5		
6	TUNER 6		
7	AUX - HDD 7		
8	USB 8		
9	BLUETOOTH 9		

Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
Display	Display / Media	CH-	CH- / Page-
BD / DVD	Shift + 2	Vol -	Vol -
VCR / DVR	Shift + 4	SP Layout	D. Menu / Top
CBL / SAT	Shift + 0	Up	Up
GAME	Shift + 5	Menu	Menu / Home
PC	Shift + Fav / Marker / PC	Left	Left
AUX	Shift + 7	Enter	OK
TUNER	Shift + 6	Right	Right
TV / CD	Shift + 3	Setup	Setup / OPT /
TV / CD	Shift + 1	Down	Down
PHONO	Shift + Guide / EPG / -/--	Return	Back / Return
PORT	Fav / Marker / PC	Home	Shift + Menu /
NET	Shift + 9	I <<	I << / Preset-
USB	Shift + 8	>>I	>>I / Preset+
Muting	Mute / Dimmer	<<	<< / Tune-
CH+	CH+ / Page+	Play	Play / Slow

Original		Replacement	
	>>	TUNE+	>> / Tune+
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie / TV	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat
THX PLAY MODE	Thx	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10 D.TUN DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer

Original		Replacement	
+10 D.TUN DIMMER	D.TUN	GOTO TEXT	Text / Goto
0	0	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original	Replacement
Power	Power
Display	Display / Media
BD / DVD	Shift + 2
VCR / DVR	Shift + 4
CBL / SAT	Shift + 0
GAME	Shift + 5
PC	Shift + Fav / Marker / PC
AUX	Shift + 7
TUNER	Shift + 6
TV / CD	Shift + 3
TV / CD	Shift + 1
PHONO	Shift + Guide / EPG / -/--
PORT	Fav / Marker / PC
NET	Shift + 9
USB	Shift + 8
Muting	Mute / Dimmer
CH+	CH+ / Page+

Original	Replacement
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
SP Layout	D. Menu / Top
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Home	Shift + Menu /
I <<	I << / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
Play	Play / Slow

Original		Replacement		Original		Replacement	
>>	>>	TUNE+	>> / Tune+	D.TUN	D. TUN	GOTO TEXT	Text / Goto
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze	0	0	HDMI-SAT 0	0
Stop	Stop	HOLD	Stop / Hold	CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MOVIE/TV SEARCH	Movie / TV	NETFLIX SEARCH	Red / Netflix / Search				
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat				
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
THX PLAY MODE	Thx	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
+10 D.TUN DIMMER	Dimmer	SHIFT +	DIMMER MUTE Shift + Mute / Dimmer				