Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
I<<	I<< / Preset-
>>I	>>I / Preset+
>>	>> / Tune+
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Original	Replacement
8	8
9	9
0	0
Info	Info / Angle
EPG	Guide / EPG / -/--
≡	Menu / Home
Source	AV / Input / RDS
Up	Up
Down	Down
Right	Right
Left	Left
OK	OK
Exit	Exit / Cancel / Clear
Smart	Smart / List
←	Back / Return
Vol+	Vol+
P+	CH+ / Page+

Original	Replacement	Original	Replacement
Vol-	VOL Vol-		
Home	SHIFT + HOME MENU Shift + Menu /		
P-	CH PAGE CH- / Page-		
NETFLIX Netflix	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /		
YouTube You Tube	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
O)I/II	LANG I/II AUDIO Audio / Lang I/II		
[≡]	GOTO TEXT Text / Goto		
SUBT Subt.	EQ SUBTITLE Subtitle / EQ		