Original		Replacement	
POWER	Power		Power
OPEN/CLOSE EJECT	Open / Close	ZOOM	Eject
DVD	DVD	HOME SMART	Smart
VCR	VCR	APP MEDIA	Media
DISPLAY CLK/CNT	Display	DISPLAY INFO	Info
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
PR/TRK	Up / PR/TRK+		Up
PR/TRK	Up / PR/TRK+	+ CH	Ch +
	Left		Left
ENTER OK	OK / Enter	OK	Ok
	Right		Right
PR/TRK	Down / PR/TRK-		Down
PR/TRK	Down / PR/TRK-	CH –	Ch -
SETUP	Setup	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
PAUSE/STEP	Pause / Step		Pause
SKIP	I<< Skip		I<<

Original		Replacement	
SKIP	>>I Skip		>>I
STOP	Stop		Stop
BACKWARD	<< Backward		<<
PLAY	Play	PLAY MODE	Play
FORWARD	>> Forward		>>
PROGRAM	Program	PROG SLEEP	Sleep
CLEAR	Clear	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement		Original	Replacement
AUDIO	Audio	SOUND DUAL	Dual		
SUBTITLE	Subtitle	AD SUBT	Subt		
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject		
ANGLE	Angle	PICTURE FORMAT	Format		
MARKER	Marker	FAV PRE-CH	Pre Ch		
SEARCH	Search	SEARCH TV/R	TV/R		
TITLE	Title	+ VOL	Vol +		
REPEAT	Repeat	REPEAT TEXT	Text		
RANDOM CM SKIP	Random	ECO 3D	3D		
A-B LP	A-B	SHIFT + REPEAT TEXT	Shift + Text		

Original		Replacement	
POWER	Power		Power
OPEN/CLOSE EJECT	Eject	ZOOM	Eject
TV/VCR	TV / VCR	TOP MENU MENU	Menu
DVD	DVD	HOME SMART	Smart
VCR	VCR	APP MEDIA	Media
AV	AV	TIMER AV	AV
DISPLAY CLK/CNT	CLK / CNT	ECO 3D	3D
PR/TRK	Up / PR/TRK+		Up
PR/TRK	Up / PR/TRK+	+ CH	Ch +
PR/TRK	Down / PR/TRK-		Down
PR/TRK	Down / PR/TRK-	CH –	Ch -
	Right		Right
	Left		Left
ENTER OK	OK	OK	Ok
SETUP i	i	DISPLAY INFO	Info
PAUSE/STEP	Pause / Step		Pause
STOP	Stop		Stop

Original		Replacement	
BACKWARD	<< Backward		<<
PLAY	Play	PLAY MODE	Play
FORWARD	>> Forward		>>
CLEAR	Clear	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
AUDIO	Audio	SOUND DUAL	Dual
SEARCH	Search	SEARCH TV/R	TV/R
RANDOM CM SKIP	CM Skip	C	Yellow

Original		Replacement	
REC/ITR	Rec / ITR	REC MODE	Rec
A-B LP	LP	PROG SLEEP	Sleep
SHOWVIEW	Show View	SETTINGS OPT	Options

Original	Replacement