Mandis shop

Hitachi RC43140P

Original	Replacement	Original	Replacement
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Home	Smart
3	3	Guide	Guide
4	4	i	Info
5	5	Back	Back
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
Lang	Dual	OK	Ok
TXT	Text	Netflix	Media
Vol +	Vol +	YouTube	Shift + Media
Vol -	Vol -	1☼	Format
Mute	Mute	Prime Video	Shift + Smart
Source	AV	Red	Red

Original	Replacement	Original	Replacement
Green	Green		
Yellow	Yellow		
Blue	Blue		
<<	<<		
Pause	Pause		
>>	>>		
Rec	Rec		
Play	Play		
Stop	Stop		