Mandis shop

# Teufel CINEBAR ONE RC

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | (( • )) | D | Blue |
| | Mute | MUTE | Mute |
| VOL | Vol+ | + VOL | Vol + |
| VOL | Vol+ | | Up |
| VOL | Vol- | VOL − | Vol - |
| VOL | Vol- | | Down |
| BASS + | Bass+ | | Right |
| BASS + | Bass+ | + CH | Ch + |
| BASS − | Bass- | | Left |
| BASS − | Bass- | CH − | Ch - |
| HDMI | HDMI | 1 | 1 |
| | Bluetooth | 2 | 2 |
| AUX | Aux | 3 | 3 |
| OPT | OPT | SETTINGS OPT | Options |
| OPT | OPT | 4 | 4 |
| MOVIE | Movie | A | Red |

| Original | | Replacement | |
|---|---|---|---|
| MUSIC | Music | B | Green |
| VOICE | Voice | C | Yellow |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

https://mandos-a-distancia.es/en/Teufel/1063159-91291-replacement-remote-control-for-Teufel-CINEBAR-ONE-RC.html