Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
P.MODE	P.Mode	PICTURE FORMAT	Format
S.MODE	S.Mode	SHIFT + SOUND DUAL	Shift + Dual
	Home	HOME SMART	Smart
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
Q.VIEW	Q.View	SETTINGS OPT	Options
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement	
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
AUDIO I/II	I/II/Audio	SOUND DUAL	Dual
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
SUBTITLE	Subtitle	AD SUBT	Subt
3D WORLD	3D World	ECO 3D	3D
INFO	Info	DISPLAY INFO	Info
FAV	FAV	FAV PRE-CH	Pre Ch
SCREEN	Screen	APP MEDIA	Media
CH.LIST	CH List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up

Original		Replacement		Original	Replacement
	Down		Down		
	Right		Right		
	Left		Left		
OK	OK	OK	Ok		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	<<		<<		
	>>		>>		
	I<<		I<<		
	>>I		>>I		
	Text	REPEAT TEXT	Text		
	Play	PLAY MODE	Play		
	Pause		Pause		
	Stop		Stop		
	Rec	REC MODE	Rec		