Mandis shop

Pioneer AXD7472

Original		Replacement	
	Power		Power
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CD	CD	CD-STB 3	3
PHONO	Phono	VIDEO 4	4
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
AUX	AUX	AUX-HDD 7	7
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
TONE/BAL	Tone/BAL	OK	OK
L/-	L/-	◀	Left
R/+	R/+	▶	Right
DIRECT	Direct	LIST SMART	Smart / List

Original	Replacement

https://mandisdistance.es/Pioneer/1659-2374-replacement-remote-control-for-Pioneer-AXD7472.html