Original		Replacement	
POWER	Power		Power
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SCA	<<	TUNE-	<< / Tune-
CAN	>>	TUNE+	>> / Tune+
SK	I<<	PRESET-	I<< / Preset-
SKIP	>>I	PRESET+	>>I / Preset+

Original		Replacement	
PLAY	Play	SLOW	Play / Slow
PAUSE/STEP	Pause/Step	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top
TITLE	Title	TITLE SOUND	Sound / Title
	Up		Up
ENTER	Enter	OK	OK
	Down		Down
	Right		Right
	Left		Left
RETURN	Return	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RESOLUTION	Resolution	PROGRAM TV/RADIO	TV/Radio /
*	*	Prime Video RANDOM	Blue / Prime Video / Random
TV POWER	Power Tv	SHIFT +	Shift + Power
AV	AV Tv	RDS AV INPUT	AV / Input / RDS
PR/CH +	PR/CH+ Tv	CH PAGE +	CH+ / Page+
PR/CH −	PR/CH- Tv	CH PAGE −	CH- / Page-
VOL +	Vol+ Tv	VOL +	Vol+
VOL −	Vol- Tv	VOL −	Vol-

Original	Replacement