Original		Replacement	
POWER	Power		Power
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
TV POWER	Power Tv	SHIFT +	Shift + Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
PR/CH	PR/CH+ Tv	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	PR/CH- Tv	CH PAGE −	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOL	Vol+ Tv	+ VOL	Vol+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0

Original		Replacement	
AV/INPUT	AV/Input	RDS AV INPUT	AV / Input / RDS
	Vol- Tv	VOL −	Vol-
SCA	<<	TUNE-	<< / Tune-
CAN	>>	TUNE+	>> / Tune+
SKI	I<<	PRESET-	I<< / Preset-
KIP	>>I	PRESET+	>>I / Preset+
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
HOME	Home	HOME MENU	Menu / Home
	Up		Up
INFO/DISPLAY	Info/Display	ANGLE INFO	Info / Angle
	Right		Right
ENTER	Enter	OK	OK
	Left		Left
BACK	Back	RETURN BACK	Back / Return
	Down		Down

Original	Replacement	Original	Replacement
DISC MENU Disc Menu	TOP MENU D.MENU D.Menu / Top		
ZOOM Zoom	SIZE ZOOM Zoom / Size		
MARKER Marker	PC FAV MARKER Fav / Marker / PC		
SEARCH Search	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /		
TITLE/POP-UP Title/Pop-Up	PROGRAM TV/RADIO TV/Radio /		
R Red	NETFLIX SEARCH Red / Netflix / Search		
G Green	APP REPEAT Green / APP / Repeat		
Y Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
B Blue	Prime Video RANDOM Blue / Prime Video / Random		
REPEAT Repeat	SHIFT + APP REPEAT Shift + Green / APP /		
AUDIO O))/Audio	LANG I/II AUDIO Audio / Lang I/II		
SUBTITLE [...]/Subtitle	EQ SUBTITLE Subtitle / EQ		
TV MUTE Tv Mute	DIMMER MUTE Mute / Dimmer		