Mandis shop

Tcl MA06405001267RC1

Original		Replacement	
	Power		Power
AUX	Aux	7	7
BT	BT	9	9
USB	USB	8	8
OPTICAL	Optical	SETUP	Setup / OPT /
HDMI IN	HDMI IN	AUDIO	Audio / Lang I/II
HDMI ARC	HDMI ARC	SUBTITLE	Subtitle / EQ
	I<<		I<< / Preset-
▶II/OK	Play/Pause/OK	OK	OK
	>>I		>>I / Preset+
BASS +	Bass+	VOL +	Vol+
BASS −	Bass-	VOL −	Vol-
+	+		Up
−	-		Down
TREBLE +	Treble+	CH PAGE +	CH+ / Page+
TREBLE −	Treble-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
VERTICAL SURROUND	Vertical Surround	LIST SMART	Smart / List
SOUND MODE	Sound Mode	MEDIA DISPLAY	Display / Media
AV SYNC −	AV Sync-	FORMAT PICTURE	Picture / Format
AV SYNC +	AV Sync+	SIZE ZOOM	Zoom / Size

https://mandos-a-distancia.es/en/Tcl/1065429-95471-replacement-remote-control-for-Tcl-MA06405001267RC1.html