Original		Replacement	
STANDBY	Standby	SHIFT +	Shift + Power
POWER	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PHONO	Phono	PC FAV MARKER	Fav / Marker / PC
TUNER	Tuner	TUNER 6	6
CD	CD	CD - STB 3	3
MULTI CH IN	Multi CH In	-/-- GUIDE EPG	Guide / EPG / -/--
V-AUX/DOCK	V-AUX	AUX - HDD 7	7
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
MD/TAPE	MD/TAPE	TAPE 5	5
CD-R	CD-R	USB 8	8
DTV	DTV	TV 1	1
VCR 1	VCR 1	VIDEO 4	4
DVR/VCR 2	DVR / VCR 2	BLUETOOTH 9	9
DVD	DVD	DVD 2	2
VOLUME +	Volume+	+ VOL	Vol+
VOLUME −	Volume-	VOL −	Vol-

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET/CH ▲	Up / Preset/CH+	▲	Up
SET MENU MENU SRCH MODE	Menu	HOME MENU	Menu / Home
PURE DIRECT	Pure Direct	OPT-TOOLS SETUP	Setup / OPT /
◄	Left / A/B/C/D/E-	◄	Left
ENTER	Enter	OK	OK
► A/B/C/D/E	Right /	►	Right
RETURN MEMORY	Return	RETURN BACK	Back / Return
▼	Down / Preset/CH-	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
STRAIGHT EFFECT	Straight Effect	PROGRAM TV/ RADIO	TV/Radio /
CLASSICAL	Classical	TITLE SOUND	Sound / Title
LIVE/CLUB	Live Club	LANG I/II AUDIO	Audio / Lang I/II
ENTERTAIN	Entertain	SIZE ZOOM	Zoom / Size
MOVIE	Movie	FORMAT PICTURE	Picture / Format
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
SUR. DECODE	Sur Decode	RDS AV INPUT	AV / Input / RDS

Original	Replacement	Original	Replacement
SELECT Select	GOTO TEXT Text / Goto		
EXTD SUR. Extd Sur.	SURROUND Eject / Surround		
NIGHT Night	LIST SMART Smart / List		
FREQ/TEXT Freq/RDS	SLOW Play / Slow		
EON EON	STEP - FREEZE Pause / Step / Freeze		
MODE – PTY SEEK PTY Seek Mode	TUNE- << / Tune-		
PTY SEEK – START PTY Seek Start	TUNE+ >> / Tune+		

Original		Replacement	
POWER	Power		Power
VOLUME +	Vol+	VOL +	Vol+
VOLUME –	Vol-	VOL –	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET/CH ▲	Preset Up	▲	Up
PRESET/CH ▲	Preset Up	PRESET+ ⏭	>>I / Preset+
◀	Left A/B/C/D/E	◀	Left
ENTER	Enter	OK	OK
▶ A/B/C/D/E	Right A/B/C/D/E	▶	Right
▼	Preset Down	PRESET- ⏮	I<< / Preset-
▼	Preset Down	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLASSICAL	1	TV 1	1
LIVE/CLUB	2	DVD 2	2
ENTERTAIN	3	CD - STB 3	3
MOVIE	4	VIDEO 4	4
STEREO	5	TAPE 5	5

Original		Replacement	
SUR. DECODE 6	6	TUNER 6	6
SELECT 7	7	AUX - HDD 7	7
EXTD SUR. 8	8	USB 8	8
1 MEMORY 9	9	BLUETOOTH 9	9
MEMORY 2 0	0	HDMI - SAT 0	0
ENHANCER	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/TEXT NET RADIO	Freq/RDS	SLOW ▶	Play / Slow
EON USB	Eon	STEP - FREEZE ⏸	Pause / Step / Freeze
MODE – PTY SEEK	Mode PTY Seek	TUNE- ◀◀	<< / Tune-
PTY SEEK – START	PTY Seek Start	TUNE+ ▶▶	>> / Tune+