Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	TV	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
	Recall	PC FAV MARKER	Fav / Marker / PC
V+	V+	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P+	P+	+ CH PAGE	CH+ / Page+

Original		Replacement	
V-	V-	VOL –	Vol -
	Nothing	LIST SMART	Smart / List
P-	P-	CH PAGE –	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
Q. MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	i	ANGLE INFO	Info / Angle
	Photo/ Movie/ Musi	MEDIA DISPLAY	Display / Media
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	*/ O	FORMAT PICTURE	Picture / Format
	*2/ Q	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement		Original		Replacement	
	[=]	GOTO TEXT	Text / Goto				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
	Lang	LANG I/II AUDIO	Audio / Lang I/II				
	[=] . .	EQ SUBTITLE	Subtitle / EQ				
	[- o-]	SIZE ZOOM	Zoom / Size				
	<<	TUNE-	<< / Tune-				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	>>	TUNE+	>> / Tune+				
	Rec	REC MODE	Rec / Rec Mode				
	Play	SLOW	Play / Slow				
	Stop	HOLD	Stop / Hold				