Original	Replacement	Original	Replacement
Power	Power	OK	OK
Red	Red / Netflix / Search	Up	Up
Rec	Rec / Rec Mode	Down	Down
Green	Green / APP / Repeat	Left	Left
<<	<< / Tune-	Right	Right
Stop	Stop / Hold	Vol +	Vol +
Yellow	Yellow / YouTube / Repeat	Vol -	Vol -
Blue	Blue / Prime Video / Random	Mute/C/P	Mute / Dimmer
Play	Play / Slow	P+	CH+ / Page+
White	Smart / List	P-	CH- / Page-
>>	>> / Tune+	1	1
[+]/A	Display / Media	2	2
[O]/B	Exit / Cancel / Clear	3	3
[ ]/C	Fav / Marker / PC	4	4
[♦]/D	Back / Return	5	5
[=]/E	Text / Goto	6	6
Menu	Menu / Home	7	7

Original		Replacement		Original		Replacement	
	8		8		> I >		D. Menu / Top
	9		9				
	0		0				
	[i +] / 13/ 24		Info / Angle				
	- / - - / P<P		Guide / EPG / - / - -				
	♪/ i . s.		Audio / Lang I/II				
	[ ] / I - II		Sound / Title				
	[<>] / DNR		Picture / Format				
	Input / Input 2		AV / Input / RDS				
	[>I <] / [PP]		Zoom / Size				
	[- O-] / [>>I]		Subtitle / EQ				
	[<>] / [. . .]		TV/ Radio /				
	[+] / [←]		Setup / OPT /				
	[1I 2] / [?]		Shift + Text /				
	[↔] / [=]		Shift + AV / Input / RDS				
	[I ><] / [X]		Pause / Step / Freeze				
	[[I]] / <→		Shift + Zoom / Size				