Original	Replacement
Display	Display / Media
Input Setup	Setup / OPT /
Speaker Setup	Menu / Home
Level Settings	Back / Return
Enter	OK
Up	Up
Down	Down
Right	Right
Left	Left
Volume+	Vol +
Volume-	Vol -
Mute	Mute / Dimmer
EQ Preset	Subtitle / EQ
System Off 1	1
System Off 2	2
System Off 3	3
System OFF 4	4

Original	Replacement
System Off 5	5
Device On AMP/ PROC/ Phono/	Power
Device Off AMP	Shift + Power
System On PROC	6
System ON Phono	7
System On TV 2	8
System On Tape	9
System On Tape	0
System On AUX	Smart / List
System ON CDR	Shift + Display / Media
System ON CDR	Shift + Smart / List

Original	Replacement
Device On 1	SHIFT + TV 1 — Shift + 1
Device On 2	SHIFT + DVD 2 — Shift + 2
Device On 3	SHIFT + CD-STB 3 — Shift + 3
Device Off	Power
Info/RDS	ANGLE INFO — Info / Angle
Time	TIMER SLEEP — Sleep / Timer
Display	MEDIA DISPLAY — Display / Media
1	TV 1 — 1
2	DVD 2 — 2
3	CD-STB 3 — 3
4	VIDEO 4 — 4
5	TAPE 5 — 5
6	TUNER 6 — 6
7	AUX-HDD 7 — 7
8	USB 8 — 8
9	BLUETOOTH 9 — 9
0	HDMI-SAT 0 — 0

Original	Replacement
Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear
Check	FORMAT PICTURE — Picture / Format
Prog	PROGRAM TV/RADIO — TV/Radio /
Input Setup	OPT-TOOLS SETUP — Setup / OPT /
Level Settings	RETURN BACK — Back / Return
Enter	OK — OK
EQ Preset	EQ SUBTITLE — Subtitle / EQ
Speaker Setup	HOME MENU — Menu / Home
Up	Up
Down	Down
Right	Right
Left	Left
Volume+	+ VOL — Vol +
Volume-	VOL — Vol -
Pause	STEP-FREEZE — Pause / Step / Freeze
Mute	DIMMER MUTE — Mute / Dimmer
<<	TUNE- — << / Tune-

Original		Replacement		Original		Replacement	
>>	>>	TUNE+	>> / Tune+				
I <<	I <<	PRESET-	I << / Preset-				
Stop	Stop	HOLD	Stop / Hold				
Play	Play	SLOW	Play / Slow				
>>I	>>I	PRESET+	>>I / Preset+				
+10	+10	PC FAV MARKER	Fav / Marker / PC				
Folder+	Folder+	CH+ PAGE	CH+ / Page+				
Folder-	Folder-	CH- PAGE	CH- / Page-				
Rep A-B	Rep A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
Repeat	Repeat	APP REPEAT	Green / APP / Repeat				
Open/Close	Open/Close	SURROUND	Eject / Surround				
Random	Random	Prime Video RANDOM	Blue / Prime Video / Random				
-10	-10	-/-- GUIDE EPG	Guide / EPG / -/--				

Original	Replacement	Original	Replacement
Device On 1	SHIFT + TV 1 — Shift + 1	FM Mode	SIZE ZOOM — Zoom / Size
Device On 2	SHIFT + DVD 2 — Shift + 2	Auto	NETFLIX SEARCH — Red / Netflix / Search
Device On 3	SHIFT + CD-STB 3 — Shift + 3	Mem	Prime Video RANDOM — Blue / Prime Video / Random
Device Off	Power	Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear
Info/RDS	ANGLE INFO — Info / Angle	Volume+	+ VOLUME — Vol +
Display	MEDIA DISPLAY — Display / Media	Volume-	VOLUME — — Vol -
1	TV 1 — 1	Scroll +	+ SCROLL — CH+ / Page+
2	DVD 2 — 2	Scroll -	SCROLL — CH PAGE — CH- / Page-
3	CD-STB 3 — 3	Up	Up
4	VIDEO 4 — 4	Down	Down
5	TAPE 5 — 5	Right	Right
6	TUNER 6 — 6	Left	Left
7	AUX-HDD 7 — 7	Enter	OK — OK
8	USB 8 — 8	Mute	DIMMER MUTE — Mute / Dimmer
9	BLUETOOTH 9 — 9	Speaker Setup	HOME MENU — Menu / Home
0	HDMI-SAT 0 — 0	Select	GOTO TEXT — Text / Goto
BAND	PROGRAM TV/RADIO — TV/Radio / Program	Input Setup	OPT-TOOLS SETUP — Setup / OPT / Tools

Original	Replacement	Original	Replacement
Level Settings	Back / Return		
EQ Preset	Subtitle / EQ		