Mandis shop

Sony RMT-708

Original		Replacement	
PLAY	Play	SLOW ▶	Play / Slow
START/STOP	Start/Stop	⏻	Power
START/STOP	Start/Stop	REC MODE ●	Rec / Rec Mode
REW ◀◀	<<	TUNE- ◀◀	<< / Tune-
FF ▶▶	>>	TUNE+ ▶▶	>> / Tune+
STOP	Stop	HOLD ■	Stop / Hold
	T	+ CH PAGE	CH+ / Page+
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
SLOW	I>/Slow		Right
SLOW	I>/Slow	SHIFT + SLOW ▶	Shift + Play /
	W	CH PAGE −	CH- / Page-
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original	Replacement

https://mandos-a-distancia.es/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html