| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| OPEN/CLOSE | Open/Close | SURROUND | Eject / Surround |
| OSD | OSD | MEDIA DISPLAY | Display / Media |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| STEP | Step | SHIFT + STEP - FREEZE | Shift + Pause / Step / |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| DVD/USB | DVD/USB | RDS AV INPUT | AV / Input / RDS |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| 0/10 | 0/10 | HDMI - SAT 0 | 0 |
| 10+ | 10+ | -/-- GUIDE EPG | Guide / EPG / -/-- |

| Original | | Replacement | |
|---|---|---|---|
| TIME | Time | TIMER SLEEP | Sleep / Timer |
| TITLE | Title | TITLE SOUND | Sound / Title |
| | Up | | Up |
| MENU | Menu | HOME MENU | Menu / Home |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | | Down |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size |
| | I<< | PRESET- | I<< / Preset- |
| L/R | L/R | NETFLIX SEARCH | Red / Netflix / Search |
| N/P | N/P | Prime Video RANDOM | Blue / Prime Video / Random |
| | << | TUNE- | << / Tune- |
| VOL- | Vol- | VOL - | Vol- |
| VOL+ | Vol+ | + VOL | Vol+ |
| | >>I | PRESET+ | >>I / Preset+ |

| Original | | Replacement | |
|---|---|---|---|
| | Play | SLOW | Play / Slow |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| | >> | TUNE+ | >> / Tune+ |
| VIDEO | Video | SHIFT + VIDEO 4 | Shift + 4 |
| PROG | Prog | PROGRAM TV/RADIO | TV/Radio / |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| A-B | A-B | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| PBC | PBC | GOTO TEXT | Text / Goto |
| RETURN | Return | RETURN BACK | Back / Return |
| SLOW | Slow | SHIFT + SLOW | Shift + Play / |
| LANGUAGE | Language | LANG I/II AUDIO | Audio / Lang I/II |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| ANGLE | Angle | ANGLE INFO | Info / Angle |
| RESET | Reset | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |