Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
	Power		Power
PRESET	< Preset	PRESET-	I<< / Preset-
PRESET	Preset >	PRESET+	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
10	10	HDMI-SAT 0	0
MEMORY	Memory	PC FAV MARKER	Fav / Marker / PC
HOME	Home	HOME MENU	Menu / Home

Original		Replacement	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
NOW PLAYING	Now Playing	-/-- GUIDE EPG	Guide / EPG / -/--
NET	Net	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
USB	USB	SHIFT + USB 8	Shift + 8
BLUETOOTH	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
RETURN	Return	RETURN BACK	Back / Return
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
DISPLAY	Display	MEDIA DISPLAY	Display / Media
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools

Original	Replacement	Original	Replacement
I <<| <<	TUNE- << / Tune-		
Stop	HOLD Stop / Hold		
>>| >>I	TUNE+ >> / Tune+		
INPUT Input Up AMP	CH PAGE + CH+ / Page+		
VOLUME Volume+ AMP	VOL + Vol +		
Power AMP	SHIFT + Power + Power		
INPUT Input Down	CH PAGE − CH- / Page-		
VOLUME Volume- AMP	VOL − Vol -		
MUTE Mute AMP	LIST SMART Smart / List		