Mandis shop

LG AKB73616006

Original		Replacement		Original	Replacement
Start	Start		Power		
Home	Home	HOME MENU	Menu / Home		
Mode	Mode	OPT-TOOLS SETUP	Setup / OPT /		
Turbo	Turbo	LIST SMART	Smart / List		
	Up		Up		
	Left		Left		
Stop OK	Stop/OK	OK	OK		
Stop OK	Stop/OK	HOLD	Stop / Hold		
	Right		Right		
	Down		Down		
Repeat	Repeat	APP REPEAT	Green / APP / Repeat		
My Space	My Space	MEDIA DISPLAY	Display / Media		
	Nothing 1	TV 1	1		
Mute	Mute	DIMMER MUTE	Mute / Dimmer		
	Nothing 2	DVD 2	2		
Diagnosis	Diagnosis	TOP MENU D.MENU	D.Menu / Top		

https://mandos-a-distancia.es/en/LG/1068089-77844-replacement-remote-control-for-LG-AKB73616006.html