Original		Replacement	
STANDBY	Standby		Power
AQT/AUTO	AQT/Auto/Open/Cl	SURROUND	Eject / Surround
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title
ANGLE LIST	List/Angle	LIST SMART	Smart / List
ASPECT	Aspect	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	Recall	RETURN BACK	Back / Return

Original		Replacement	
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
REC	Rec	REC MODE	Rec / Rec Mode
INFO	Info	ANGLE INFO	Info / Angle
D.PROG TV/R	Red/D.Prog/Tv/	NETFLIX SEARCH	Red / Netflix / Search
STEP	Green/Step	APP REPEAT	Green / APP / Repeat
RPT	Yellow/RPT	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A-B SCR	Blue/A-B/SCR	Prime Video RANDOM	Blue / Prime Video / Random
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INPUT	Input	RDS AV INPUT	AV / Input / RDS
	Left		Left
ENTER	OK	OK	OK
	Right		Right
DVD SETUP EXIT	DVD Setup/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOL +	Vol +	VOL +	Vol +

Original	Replacement	Original	Replacement
Mute	Mute / Dimmer		
CH+	CH+ / Page+		
Vol -	Vol -		
Audio	Audio / Lang I/II		
CH-	CH- / Page-		
[=] / Slow	Text / Goto		
[=▲] / Stop	Stop / Hold		
[=▼] / Zoom	Zoom / Size		
[=i] / I<<	I<< / Preset-		
[+] / Play/Pause	Play / Slow		
[♦] / >>I	>>I / Preset+		
[=?] / <<	<< / Tune-		
EPG/D. Menu	Guide / EPG / -/--		
[=o] / >>	>> / Tune+		
FAV-/D. Disp	SHIFT + CH- /		
FAV/D. Title	Fav / Marker / PC		
FAV+/D. Goto	SHIFT + CH+ / Page+		

Original		Replacement	
STANDBY	Standby		Power
AQT/AUTO	AQT/Auto/Open/Cl	SURROUND	Eject / Surround
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title
ANGLE LIST	List/Angle	LIST SMART	Smart / List
ASPECT	Aspect	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	Recall	RETURN BACK	Back / Return

Original		Replacement	
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
REC	Rec	REC MODE	Rec / Rec Mode
INFO	Info	ANGLE INFO	Info / Angle
D.PROG TV/R	Red/D.Prog/Tv/	NETFLIX SEARCH	Red / Netflix / Search
STEP	Green/Step	APP REPEAT	Green / APP / Repeat
RPT	Yellow/RPT	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A-B SCR	Blue/A-B/SCR	Prime Video RANDOM	Blue / Prime Video / Random
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INPUT	Input	RDS AV INPUT	AV / Input / RDS
	Left		Left
ENTER	OK	OK	OK
	Right		Right
DVD SETUP EXIT	DVD Setup/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOL +	Vol +	VOL +	Vol +

Original	Replacement	Original	Replacement
Mute	Mute / Dimmer		
CH+	CH+ / Page+		
Vol -	Vol -		
Audio	Audio / Lang I/II		
CH-	CH- / Page-		
[=] / Slow	Text / Goto		
[=▲] / Stop	Stop / Hold		
[=▼] / Zoom	Zoom / Size		
[=i] / I<<	I<< / Preset-		
[+] / Play/Pause	Play / Slow		
[♦] / >>I	>>I / Preset+		
[=?] / <<	<< / Tune-		
EPG/D. Menu	Guide / EPG / -/--		
[=o] / >>	>> / Tune+		
FAV-/D. Disp	SHIFT + CH- /		
FAV/D. Title	Fav / Marker / PC		
FAV+/D. Goto	SHIFT + CH+ / Page+		