Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
COI/II LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
	Vol +	+ VOL	Vol +
SETTING	☼/ Setting	OPT-TOOLS SETUP	Setup / OPT /
P	P+	+ CH PAGE	CH+ / Page+

Original		Replacement	
	Vol -	VOL −	Vol -
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
P	P-	CH PAGE −	CH- / Page-
MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
S.MODE	S. Mode	TITLE SOUND	Sound / Title
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement		Original		Replacement	
SUB.T	Green	APP REPEAT	Green / APP / Repeat				
SUB.T	Sub. T	EQ SUBTITLE	Subtitle / EQ				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
MOUSE	Blue/ Mouse	Prime Video RANDOM	Blue / Prime Video / Random				
	Play	SLOW	Play / Slow				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Stop	HOLD	Stop / Hold				
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
	I <<	PRESET-	I << / Preset-				
	>>I	PRESET+	>>I / Preset+				
REC	Rec	REC MODE	Rec / Rec Mode				