Mandis shop

Denon RC-176

Original	Replacement
A-B Deck	Yellow / YouTube / Repeat
Rec Deck	Rec / Rec Mode
Pause Deck	Down
Stop Deck	OK
<< Deck	<< / Tune-
>> Deck	>> / Tune+
< Play Deck	Left
Play > Deck	Right
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Random CD	Blue / Prime Video / Random
Repeat CD	Green / APP / Repeat
Disc Skip CD	Eject / Surround
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
Play CD	Play / Slow
Preset Up Tuner	Shift + >>I / Preset+

Original	Replacement
Preset Up Tuner	CH+ / Page+
Tape 2	2
Tape 1	5
AUX	7
Preset Down	CH- / Page-
Preset Down	Shift + I<< / Preset-
Tuner	6
CD	3
Phono	4
Vol +	Vol +
Vol -	Vol -
Power	Power
Muting	Mute / Dimmer

https://mandisshop.com/Denon/1336284-replacement-remote-control-for-Denon-RC-176-902704.htm