Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/ AV		0
	P/ C/ CL	FAV PRE-CH	Pre Ch
	Pause		Pause
	<<		<<
	Pl ay	PLAY MODE	Pl ay
	>>		>>
	TXT	REPEAT TEXT	Text

Original		Replacement	
	i	DISPLAY INFO	I nf o
	P+	+ CH	Ch +
	P-	CH –	Ch -
	Up		Up
	Down		Down
	Ri ght		Ri ght
	Lef t		Lef t
	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Audi o	SOUND DUAL	Dual
	Bl ue	D	Bl ue
	Yel l ow	C	Yel l ow
	Gr een	B	Gr een
	Red/ OTR	A	Red
	Next		>>I
	Prev		I <<

Original		Replacement	
	Stop		Stop
OTR	Rec	REC MODE	Rec
☼+	☼+	ECO 3D	3D
- ☼	- ☼	PICTURE FORMAT	Format
☺+	☺+	HOME SMART	Smart
- ☺	- ☺	APP MEDIA	Media

Original	Replacement

Original		Replacement	
	Power		Power
	Pause		Pause
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	i	DISPLAY INFO	Info
OTR	Rec	REC MODE	Rec
	Stop		Stop
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
P+	Up		Up
P-	Down		Down
+	☺+	HOME SMART	Smart
−	-☺	APP MEDIA	Media

Original	Replacement

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	P/C/CL	FAV PRE-CH	Pre Ch
	Pause		Pause
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
TXT	TXT	REPEAT TEXT	Text

Original		Replacement	
	i	DISPLAY INFO	Info
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	+ CH	Ch +
P-	P-	CH –	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Audio	SOUND DUAL	Dual
NEXT	Blue	D	Blue
PREV.	Yellow	C	Yellow
	Green	B	Green
OTR	Red/OTR	A	Red
NEXT	Next		>>I
PREV.	Prev		I <<

Original		Replacement	
	Stop		Stop
OTR	Rec	REC MODE	Rec
☼+	☼+	ECO 3D	3D
- ☼	- ☼	PICTURE FORMAT	Format
☺+	☺+	HOME SMART	Smart
- ☺	- ☺	APP MEDIA	Media

Original	Replacement