Original		Replacement	
	Index	SLOW	Play / Slow
-1	Red / -1	NETFLIX SEARCH	Red / Netflix / Search
/ +1	Green / Timer /	APP REPEAT	Green / APP / Repeat
STOP	Yellow / Stop	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / Reveal	Prime Video RANDOM	Blue / Prime Video / Random
	[≡]]]	REC MODE	Rec / Rec Mode
	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Size	SIZE ZOOM	Zoom / Size
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
	Text	GOTO TEXT	Text / Goto
	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
TINT	Tint-	SHIFT +	Shift + Left
TINT	Tint+	SHIFT +	Shift + Right
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Replacement	
6	6	TUNER 6	6
	Contrast-	TUNE-	<< / Tune-
	Contrast+	TUNE+	>> / Tune+
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Brightness-	PRESET-	I<< / Preset-
	Brightness+	PRESET+	>>I / Preset+
P/C	P/C	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
AV	AV	RDS AV INPUT	AV / Input / RDS
	←•→	MEDIA DISPLAY	Display / Media
	**	LIST SMART	Smart / List
PIP	PIP	FORMAT PICTURE	Picture / Format
i	i	ANGLE INFO	Info / Angle
i	i	HOME MENU	Menu / Home
	----	EQ SUBTITLE	Subtitle / EQ

Original		Replacement	
P	Up / P+		Up
P	Up / P+	CH PAGE +	CH+ / Page+
	Mute	DIMMER MUTE	Mute / Dimmer
	Left / Vol-		Left
	Left / Vol-	VOL −	Vol-
OK	OK	OK	OK
	Right / Vol+		Right
	Right / Vol+	VOL +	Vol+
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
P	Down / P-		Down
P	Down / P-	CH PAGE −	CH- / Page-
	Power		Power

Original	Replacement

Original		Replacement		Original	Replacement
	<	PRESET-	I<< / Preset-		
	>	PRESET+	>>I / Preset+		
	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Pause	STEP - FREEZE	Pause / Step / Freeze		
	Play	SLOW	Play / Slow		
	P+	CH PAGE +	CH+ / Page+		
	P-	CH PAGE −	CH- / Page-		
	Power		Power		

Original		Replacement	
-1	Red	NETFLIX SEARCH	Red / Netflix / Search
/ +1	Green/Timer	APP REPEAT	Green / APP / Repeat
STOP	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	TXT	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
-O	-O	TUNE-	<< / Tune-
O+	O+	TUNE+	>> / Tune+
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-☼	-☼	PRESET-	I<< / Preset-

Original		Replacement	
	☼+	PRESET+	>>I / Preset+
P/C	P/C	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
PIP	PIP	FORMAT PICTURE	Picture / Format
i	i	ANGLE INFO	Info / Angle
P	P+	+ CH PAGE	CH+ / Page+
P	Up		Up
	Mute	DIMMER MUTE	Mute / Dimmer
	Left		Left
	Vol-	VOL −	Vol-
OK	OK	OK	OK
	Right		Right
	Vol+	+ VOL	Vol+
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
P	P-	CH PAGE −	CH- / Page-
P	Down		Down
	Power		Power