Original		Replacement	
MONITOR (TV/VIDEO)	Monitor	PROGRAM TV/RADIO	TV/Radio /
TV PROGRAM	Tv Program(TV)-	SHIFT + CH PAGE −	Shift + CH- /
TV PROGRAM	Tv Program(TV)+	SHIFT + CH PAGE +	Shift + CH+ /
OSD	OSD	TOP MENU D.MENU	D.Menu / Top
TV VOLUME −	Tv Volume-	VOL −	Vol -
TV VOLUME +	Tv Volume+	+ VOL	Vol +
C.RESET	C.Reset	ANGLE INFO	Info / Angle
TIMER	Timer	TIMER SLEEP	Sleep / Timer
SELECT	Select	OK	OK
SET − CURSOR	Set-/Cursor Left	◀	Left
SET + CURSOR	Set+/Cursor Right	▶	Right
MEMORY CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Replacement	
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
DAILY 8	8	USB 8	8
REPEAT 9	9	BLUETOOTH 9	9
AUX 0	0/AUX	HDMI-SAT 0	0
AUX 0	0/AUX	SHIFT + AUX-HDD 7	Shift + 7
ERASE	Erase	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
[+]	[+]	EQ SUBTITLE	Subtitle / EQ
Timer	Timer	LIST SMART	Smart / List
Timer-	Timer-	▼	Down
Timer+	Timer+	▲	Up
Red	Red	NETFLIX SEARCH	Red / Netflix / Search
Green	Green	APP REPEAT	Green / APP / Repeat
Yellow	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
Blue	Blue	Prime Video RANDOM	Blue / Prime Video / Random
MENU/TEXT	Menu/Text	HOME MENU	Menu / Home

Original	Replacement	Original	Replacement
Operate (VTR)	Power		
I<	I<< / Preset-		
Play	Play / Slow		
>I	>>I / Preset+		
Eject	Eject / Surround		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Tv Program	CH- / Page-		
TV Program	CH+ / Page+		
Index	Text / Goto		
Skip/Blank	Setup / OPT /		
SP/LP	Picture / Format		
<< V. Search	<< / Tune-		
V. Search >>	>> / Tune+		

https://mandisdistance.com/JVC-RM-RK-replacement-remote-control-for-JVC-RM-RK-RK-RK