Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
RECALL	Recall	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
INFO	Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up

Original		Replacement	
	Left		Left
OK	OK	OK	OK
	Right		Right
SAT	Sat	SHIFT + HDMI - SAT 0	Shift + 0
	Down		Down
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
FREEZE	Freeze	STEP - FREEZE II	Pause / Step / Freeze
AUX IN	Aux In	RDS AV INPUT	AV / Input / RDS
UHF	UHF	LIST SMART	Smart / List
AUDIO	Red / Audio	LANG I/II AUDIO	Audio / Lang I/II
AUDIO	Red / Audio	NETFLIX SEARCH	Red / Netflix / Search
POSITIONER	Green / Position	APP REPEAT	Green / APP / Repeat
TEXT	Yellow / Text	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TEXT	Yellow / Text	GOTO TEXT	Text / Goto
AUDIO R/L	Blue / Audio R/L	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement	Original	Replacement
Blue / Audio R/	Sound / Title		