Original		Replacement	
POWER	Power		Power
INPUT D/A	Input D/A	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
TEXT	Text	GOTO TEXT	Text / Goto
INPUT	Input Source	RDS AV INPUT	AV / Input / RDS
GHT	Bright+	SHIFT +	Shift + Up
BRI	Bright-	SHIFT +	Shift + Down
RATIO	Ratio	FORMAT PICTURE	Picture / Format
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement	
	Rec	REC MODE	Rec / Rec Mode
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
BACK	Back	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
INFO	Info	ANGLE INFO	Info / Angle
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -

Original		Replacement		Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	INDEX	Index	SIZE ZOOM	Zoom / Size
PR+	PR+	CH PAGE +	CH+ / Page+	TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
PR-	PR-	CH PAGE −	CH- / Page-	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC	HOLD	Hold	SHIFT + HOLD	Shift + Stop /
1	1	TV 1	1	REVEAL	Reveal	TITLE SOUND	Sound / Title
2	2	DVD 2	2	SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI - SAT 0	0				
LIST	List	LIST SMART	Smart / List				
Q.VIEW	Q. View	TOP MENU D.MENU	D. Menu / Top				
UPDATE	Update	OPT-TOOLS SETUP	Setup / OPT / Tools				

Original		Replacement	
POWER	Power		Power
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	<<	TUNE-	<< / Tune-
	I <<	PRESET-	I << / Preset-
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Replacement	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Replacement	
POWER	Power		Power
INPUT	Input Source	RDS AV INPUT	AV / Input / RDS
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
PR +	PR+	CH PAGE +	CH+ / Page+
PR −	PR-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0