Mandis shop

LG AKB75675312

Original		Replacement	
	Power		Power
	Tv/Rad	PROGRAM TV/RADIO	TV/Radio /
	Search/*	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	☼	OPT-TOOLS SETUP	Setup / OPT /
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0

Original		Replacement	
	.../*	MEDIA DISPLAY	Display / Media
	Vol+	+ VOL	Vol+
QUICK ACCESS FAV	FAV//Quic Acces/*	PC FAV MARKER	Fav / Marker / PC
	CH+	+ CH PAGE	CH+ / Page+
	Vol-	VOL −	Vol-
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	CH-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
TEXT	Text	GOTO TEXT	Text / Goto
	Home	HOME MENU	Menu / Home
T.OPT	T.Opt.	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
BACK	Back	RETURN BACK	Back / Return
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
	OK	OK	OK
	Right		Right

Original		Replacement	
AD/*	AD/*	AUDIO (LANG I/II)	Audio / Lang I/II
▽	Down	▼	Down
Q.MENU/*	Q.Menu/*	D.MENU (TOP MENU)	D.Menu / Top
MOVIES/*	Movies	PICTURE (FORMAT)	Picture / Format
REC/*	Rec/*	● (REC MODE)	Rec / Rec Mode
□	Stop	■ (HOLD)	Stop / Hold
◀◀	<<	◀◀ (TUNE-)	<< / Tune-
▷	Play	▶ (SLOW)	Play / Slow
II	Pause	II (STEP-FREEZE)	Pause / Step / Freeze
▶▶	>>	▶▶ (TUNE+)	>> / Tune+
●	Red	NETFLIX (SEARCH)	Red / Netflix / Search
●●	Green	APP (REPEAT)	Green / APP / Repeat
●●	Yellow	YouTube (REPEAT A-B)	Yellow / YouTube / Repeat
●●	Blue	Prime Video (RANDOM)	Blue / Prime Video / Random

Original	Replacement