Original		Replacement	
POWER	Power		Power
TV/AV	Tv/Av	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
– LIST	-List	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
Q.VIEW	Q.View	LIST SMART	Smart / List
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MEMORY/ERASE	Memory/Erase	PC FAV MARKER	Fav / Marker / PC
A.PROG	A.Prog	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL	Vol -	VOL	Vol -
CH	CH Up	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
CH	CH Down	CH PAGE	CH- / Page-
REW	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FF	>>	TUNE+	>> / Tune+
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
PSM	PSM	YouTube / REPEAT A-B	Yellow / YouTube / Repeat	INDEX	Index	ANGLE / INFO	Info / Angle
▼	Down	▼	Down				
SSM	SSM	Prime Video / RANDOM	Blue / Prime Video / Random				
PIP	PIP	FORMAT / PICTURE	Picture / Format				
PR –	PR-	SHIFT +	CH PAGE – Shift + CH- /				
PR +	PR+	SHIFT +	+ CH PAGE Shift + CH+ /				
MTS	MTS	NETFLIX / SEARCH	Red / Netflix / Search				
FCR	FCR	APP / REPEAT	Green / APP / Repeat				
RATIO	Ratio	TOP MENU / D.MENU	D.Menu / Top				
MULTIMEDIA	Multimedia	MEDIA / DISPLAY	Display / Media				
TEXT	Text	GOTO / TEXT	Text / Goto				
SUBTITLE	Subtitle	EQ / SUBTITLE	Subtitle / EQ				
PIP INPUT	PIP Input	SHIFT +	SIZE / ZOOM Shift + Zoom /				
POSITION	Position	OPT-TOOLS / SETUP	Setup / OPT /				
SWAP	Swap	RETURN / BACK	Back / Return				
SIZE	Size	SIZE / ZOOM	Zoom / Size				
STILL	Still	SHIFT +	STEP - FREEZE / II Shift + Pause / Step / Freeze				