Original		Replacement		Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer	9 wxyz	9	BLUETOOTH 9	9
	Power		Power	0 AV	0/AV	HDMI - SAT 0	0
TV	TV	SHIFT +	TV 1 Shift + 1	MUSIC-ID EPG	EPG/Music-ID	-/-- GUIDE EPG	Guide / EPG / -/--
REC	REC	SHIFT +	VIDEO 4 Shift + 4	MEDIA	Media	MEDIA DISPLAY	Display / Media
DVD	DVD	SHIFT +	DVD 2 Shift + 2	INPUT PIP	PIP/Input	RDS AV INPUT	AV / Input / RDS
AUDIO	Audio	SHIFT +	CD - STB 3 Shift + 3	DISC-M TEXT	Text/Disc-M	GOTO TEXT	Text / Goto
	Timer	TIMER SLEEP	Sleep / Timer	TITLE MENU	Menu/Title	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size	END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Audio	LANG I/II AUDIO	Audio / Lang I/II	INFO	Info	ANGLE INFO	Info / Angle
1	1	TV 1	1	+V	V+	+ VOL	Vol +
2 abc	2	DVD 2	2		Left		Left
3 def	3	CD - STB 3	3		Up		Up
4 ghi	4	VIDEO 4	4	P+	P+	+ CH PAGE	CH+ / Page+
5 jkl	5	TAPE 5	5		Right		Right
6 mno	6	TUNER 6	6	OK	OK	OK	OK
7 pqrs	7	AUX - HDD 7	7	-V	V-	VOL −	Vol -
8 tuv	8	USB 8	8		Down		Down

Original	Replacement	Original	Replacement
P-	CH- / Page-		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue/Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec/Back	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Replacement		Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer	9 wxyz	9	BLUETOOTH 9	9
	Power		Power	0 AV	0/AV	HDMI - SAT 0	0
TV	TV	SHIFT +	TV 1 Shift + 1	MUSIC-ID EPG	EPG/Music-ID	-/-- GUIDE EPG	Guide / EPG / -/--
REC	REC	SHIFT +	VIDEO 4 Shift + 4	MEDIA	Media	MEDIA DISPLAY	Display / Media
DVD	DVD	SHIFT +	DVD 2 Shift + 2	INPUT PIP	PIP/Input	RDS AV INPUT	AV / Input / RDS
AUDIO	Audio	SHIFT +	CD - STB 3 Shift + 3	DISC-M TEXT	Text/Disc-M	GOTO TEXT	Text / Goto
	Timer	TIMER SLEEP	Sleep / Timer	TITLE MENU	Menu/Title	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size	END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Audio	LANG I/II AUDIO	Audio / Lang I/II	INFO	Info	ANGLE INFO	Info / Angle
1	1	TV 1	1	+V	V+	+ VOL	Vol +
2 abc	2	DVD 2	2		Left		Left
3 def	3	CD - STB 3	3		Up		Up
4 ghi	4	VIDEO 4	4	P+	P+	+ CH PAGE	CH+ / Page+
5 jkl	5	TAPE 5	5		Right		Right
6 mno	6	TUNER 6	6	OK	OK	OK	OK
7 pqrs	7	AUX - HDD 7	7	-V	V-	VOL −	Vol -
8 tuv	8	USB 8	8		Down		Down

Original	Replacement	Original	Replacement
P-	CH- / Page-		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue/Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec/Back	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original	Replacement
Mute	Mute / Dimmer
Power	Power
TV	Shift + 1
REC	Shift + 4
DVD	Shift + 2
Audio	Shift + 3
Timer	Sleep / Timer
Zoom	Zoom / Size
Audio	Audio / Lang I/II
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Replacement
9	9
0/AV	0
EPG-Music-ID	Guide / EPG / -/--
Media	Display / Media
PIP/Input	AV / Input / RDS
Text/Disc-M	Text / Goto
Menu/Title	Menu / Home
End	Exit / Cancel / Clear
Info	Info / Angle
V+	Vol +
Left	Left
Up	Up
P+	CH+ / Page+
Right	Right
OK	OK
V-	Vol -
Down	Down

Original	Replacement	Original	Replacement
P-	CH- / Page-		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue/Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec/Back	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Replacement		Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer	9 wxyz	9	BLUETOOTH 9	9
	Power		Power	0 AV	0/AV	HDMI - SAT 0	0
TV	TV	SHIFT + TV 1	Shift + 1	MUSIC-ID EPG	EPG/Music-ID	-/-- GUIDE EPG	Guide / EPG / -/--
REC	REC	SHIFT + VIDEO 4	Shift + 4	MEDIA	Media	MEDIA DISPLAY	Display / Media
DVD	DVD	SHIFT + DVD 2	Shift + 2	INPUT PIP	PIP/Input	RDS AV INPUT	AV / Input / RDS
AUDIO	Audio	SHIFT + CD - STB 3	Shift + 3	DISC-M TEXT	Text/Disc-M	GOTO TEXT	Text / Goto
	Timer	TIMER SLEEP	Sleep / Timer	TITLE MENU	Menu/Title	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size	END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Audio	LANG I/II AUDIO	Audio / Lang I/II	INFO	Info	ANGLE INFO	Info / Angle
1	1	TV 1	1	+V	V+	+ VOL	Vol +
2 abc	2	DVD 2	2		Left		Left
3 def	3	CD - STB 3	3		Up		Up
4 ghi	4	VIDEO 4	4	P+	P+	+ CH PAGE	CH+ / Page+
5 jkl	5	TAPE 5	5		Right		Right
6 mno	6	TUNER 6	6	OK	OK	OK	OK
7 pqrs	7	AUX - HDD 7	7	-V	V-	VOL −	Vol -
8 tuv	8	USB 8	8		Down		Down

Original	Replacement	Original	Replacement
P-	CH- / Page-		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue/Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec/Back	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		