Original	Replacement
System Power	Power
System Power Off	Shift + Power
Source On/Off	Red / Netflix / Search
Source On/Off	Green / APP / Repeat
Source On/Off	Blue / Prime Video / Random
Source On/Off CD	Yellow / YouTube / Repeat
Source On/Off	Shift + Red / Netflix /
Source On/Off	Shift + Green / APP /
Source On/Off	Shift + Yellow / YouTube /
Source On/Off MD	Shift + Blue / Prime
Source On/Off	Shift + Fav / Marker / PC
Phono	Shift + 1
CD	Shift + 3
Tuner	Shift + 6
CD-R	Shift + 2
AUX1	Shift + 7
AUX2	Shift + 8

Original	Replacement
Tape	Shift + 5
MD	Shift + 4
1 Tuner	1
2 Tuner	2
3 Tuner	3
A. F/P Tuner	Guide / EPG / -/--
4 Tuner	4
5 Tuner	5
6 Tuner	6
B. -/-- Tuner	Fav / Marker / PC
7 Tuner	7
8 Tuner	8
9 Tuner	9
Mode Tuner	Smart / List
- Tuner	CH- / Page-
0 Tuner	0
+ Tuner	CH+ / Page+

Original	Replacement	Original	Replacement
Memo Tuner	Display / Media		
Scroll Tuner	Back / Return		
Cancel Tuner	Exit / Cancel / Clear		
Text / Mode 1	Text / Goto		
Time/Mode 2	Sleep / Timer		
I << Tuner	I << / Preset-		
>>I Tuner	>>I / Preset+		
Mute	Mute / Dimmer		
<< Tuner	<< / Tune-		
>> Tuner	>> / Tune+		
Vol +	Vol +		
Vol -	Vol -		

Original		Replacement	
SYSTEM ON	System Power		Power
POWER OFF	System Power Off	SHIFT +	Shift + Power
SOURCE ON/OFF	Source On/Off	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
SOURCE ON/OFF	Source On/Off	NETFLIX SEARCH	Red / Netflix / Search
SOURCE ON/OFF	Source On/Off	APP REPEAT	Green / APP / Repeat
SOURCE ON/OFF	Source On/Off CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SOURCE ON/OFF	Source On/Off	Prime Video RANDOM	Blue / Prime Video / Random
SOURCE ON/OFF	Source On/Off	SHIFT + APP REPEAT	Shift + Green / APP /
SOURCE ON/OFF	Source On/Off	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
SOURCE ON/OFF	Source On/Off MD	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
SOURCE ON/OFF	Source On/Off	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
PHONO	Phono	SHIFT + TV 1	Shift + 1
CD	CD	SHIFT + CD-STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
CD-R	CD-R	SHIFT + DVD 2	Shift + 2
AUX 1	AUX1	SHIFT + AUX-HDD 7	Shift + 7
AUX 2	AUX2	SHIFT + USB 8	Shift + 8

Original		Replacement	
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
MD	MD	SHIFT + VIDEO 4	Shift + 4
1	1 CDR	TV 1	1
2	2 CDR	DVD 2	2
3	3 CDR	CD-STB 3	3
4	4 CDR	VIDEO 4	4
5	5 CDR	TAPE 5	5
6	6 CDR	TUNER 6	6
7	7 CDR	AUX-HDD 7	7
8	8 CDR	USB 8	8
9	9 CDR	BLUETOOTH 9	9
MODE	Mode CDR	LIST SMART	Smart / List
-	- CDR	CH PAGE -	CH- / Page-
0	0 CDR	HDMI-SAT 0	0
+	+ CDR	CH PAGE +	CH+ / Page+
MEMO	Memo CDR	MEDIA DISPLAY	Display / Media
SCROLL	Scroll CDR	RETURN BACK	Back / Return

Original	Replacement	Original	Replacement
Cancel CDR	Exit / Cancel / Clear		
Text / Mode 1	Text / Goto		
Time / Mode 2	Sleep / Timer		
I << CDR	I << / Preset-		
Play CDR	Play / Slow		
>>I CDR	>>I / Preset+		
Mute	Mute / Dimmer		
<< CDR	<< / Tune-		
Stop CDR	Stop / Hold		
>> CDR	>> / Tune+		
Vol +	Vol +		
Pause CDR	Pause / Step / Freeze		
Open/Close	Eject / Surround		
Vol -	Vol -		

Original	Replacement	Original	Replacement
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Shift + Yellow / YouTube /	1 Tape	1
Source On/Off	Red / Netflix / Search	2 Tape	2
Source On/Off	Green / APP / Repeat	3 Tape	3
Source On/Off CD	Yellow / YouTube / Repeat	A. F/P Tape	Guide / EPG / -/--
Source On/Off	Blue / Prime Video / Random	4 Tape	4
Source On/Off	Shift + Red / Netflix /	5 Tape	5
Source On/Off	Shift + Green / APP /	6 Tape	6
Source On/Off MD	Shift + Blue / Prime	B. -/-- Tape	Fav / Marker / PC
Source On/Off	Shift + Fav / Marker / PC	7 Tape	7
Phono	Shift + 1	8 Tape	8
CD	Shift + 3	9 Tape	9
Tuner	Shift + 6	Mode Tape	Smart / List
CD-R	Shift + 2	- Tape	CH- / Page-
AUX1	Shift + 7	0 Tape	0
AUX2	Shift + 8	+ Tape	CH+ / Page+

Original	Replacement	Original	Replacement
Memo Tape	Display / Media		
Cancel Tape	Exit / Cancel / Clear		
Text / Mode 1	Text / Goto		
Time / Mode 2	Sleep / Timer		
I << Tape	I << / Preset-		
Play Tape	Play / Slow		
>>I Tape	>>I / Preset+		
Mute	Mute / Dimmer		
<< Tape	<< / Tune-		
Stop Tape	Stop / Hold		
>> Tape	>> / Tune+		
Vol +	Vol +		
<> Tape	Rec / Rec Mode		
Pause Tape	Pause / Step / Freeze		
Open/Close	Eject / Surround		
Vol -	Vol -		

Original	Replacement	Original	Replacement
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Red / Netflix / Search	1 CD	1
Source On/Off CD	Yellow / YouTube / Repeat	2 CD	2
Source On/Off	Green / APP / Repeat	3 CD	3
Source On/Off	Blue / Prime Video / Random	A. F/P CD	Guide / EPG / -/--
Source On/Off	Shift + Red / Netflix /	4 CD	4
Source On/Off	Shift + Green / APP /	5 CD	5
Source On/Off	Shift + Yellow / YouTube /	6 CD	6
Source On/Off MD	Shift + Blue / Prime	B. -/-- CD	Fav / Marker / PC
Source On/Off	Shift + Fav / Marker / PC	7 CD	7
Phono	Shift + 1	8 CD	8
CD	Shift + 3	9 CD	9
Tuner	Shift + 6	Mode CD	Smart / List
CD-R	Shift + 2	- CD	CH- / Page-
AUX1	Shift + 7	0 CD	0
AUX2	Shift + 8	+ CD	CH+ / Page+

Original	Replacement	Original	Replacement
Memo CD	Display / Media		
Scroll CD	Back / Return		
Cancel CD	Exit / Cancel / Clear		
Text / Mode 1 CD	Text / Goto		
Time / Mode 2 CD	Sleep / Timer		
I << CD	I << / Preset-		
Play CD	Play / Slow		
>>I CD	>>I / Preset+		
Mute	Mute / Dimmer		
<< CD	<< / Tune-		
Stop CD	Stop / Hold		
>> CD	>> / Tune+		
Vol +	Vol +		
Pause CD	Pause / Step / Freeze		
Open/Close CD	Eject / Surround		
Vol -	Vol -		