Original		Replacement	
ON/STANDBY	On/Standby		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DVD/BD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + BLUETOOTH 9	Shift + 9
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TV/TAPE	TV / TAPE	SHIFT + TAPE 5	Shift + 5
TV/TAPE	TV / TAPE	SHIFT + TV 1	Shift + 1
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PORT	PORT	SHIFT + USB 8	Shift + 8
CD	CD	SHIFT + CD - STB 3	Shift + 3
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc/Album	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
ALBUM	CH/Disc/Album	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -

Original		Replacement	
	Up		Up
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat

Original		Replacement		Original	Replacement
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
STEREO PLAY MODE	Stereo	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10	+10/ - - / - - - 10/ Dimmer / D. Tun	-/-- GUIDE EPG	Guide / EPG / - / - -		
0	0/ 11	HDMI - SAT 0	0		
CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		
CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original	Replacement	Original	Replacement
Power BD/DVD	Power	<< BD/DVD	<< / Tune-
DVD/BD	Smart / List	Play BD/DVD	Play / Slow
CBL/SAT	Display / Media	>> BD/DVD	>> / Tune+
Vol + Receiver	Vol +	Pause BD/DVD	Pause / Step / Freeze
Vol - Receiver	Vol -	Stop BD/DVD	Stop / Hold
Top Menu	D. Menu / Top	Search BD/DVD	Red / Netflix / Search
Up BD/DVD	Up	Repeat BD/DVD	Green / APP / Repeat
Menu BD/DVD	Menu / Home	Random	Blue / Prime Video / Random
Left BD/DVD	Left	Play Mode	Yellow / YouTube / Repeat
Enter BD/DVD	OK	1 BD/DVD	1
Right BD/DVD	Right	2 BD/DVD	2
Setup BD/DVD	Setup / OPT /	3 BD/DVD	3
Down BD/DVD	Down	4 BD/DVD	4
Return BD/DVD	Back / Return	5 BD/DVD	5
Audio BD/DVD	Audio / Lang I/II	6 BD/DVD	6
I << BD/DVD	I << / Preset-	7 BD/DVD	7
>>I BD/DVD	>>I / Preset+	8 BD/DVD	8

Original	Replacement
9 BD/DVD	9
+10/--/--10	Guide / EPG / -/--
0/11 BD/DVD	0
CLR/12 BD/DVD	Fav / Marker / PC
CLR/12 BD/DVD	Exit / Cancel / Clear
Power CBL/SAT	Shift + Power
CH Disc/Album+ CBL/SAT	Shift + CH+ /
CH Disc/Album- CBL/SAT	Shift + CH- /
Guide CBL/SAT	Shift + Guide / EPG / -/--
Up CBL/SAT	Shift + Up
Menu/Prev CH CBL/SAT	Shift + Menu /
Left CBL/SAT	Shift + Left
Enter CBL/SAT	Shift + OK
Right CBL/SAT	Shift + Right
Setup CBL/SAT	Shift + Setup / OPT / Tools
Down CBL/SAT	Shift + Down
Return CBL/SAT	Shift + Back / Return

Original	Replacement
<< CBL/SAT	Shift + << /
Play CBL/SAT	Shift + Play /
>> CBL/SAT	Shift + >> /
Pause CBL/SAT	Shift + Pause / Step /
Stop CBL/SAT	Shift + Stop /
Movie Tv/Search CBL/SAT	Shift + Red / Netflix /
Music/Repeat CBL/SAT	Shift + Green / APP /
Game/Random	Shift + Yellow / YouTube /
Stereo/Play Mode CBL/SAT	Shift + Blue / Prime
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8

Original		Replacement	Original	Replacement
9	9 CBL/SAT	SHIFT + BLUETOOTH 9		
0 11	0/11 CBL/SAT	SHIFT + HDMI - SAT 0		

Original		Replacement	
ON/STANDBY	Power CD		Power
CD	CD	LIST SMART	Smart / List
CH/Disc+	CH/Disc+ CD	CH PAGE +	CH+ / Page+
VOL	Vol + Receiver	VOL +	Vol +
ALBUM	CH/Disc- CD	CH PAGE −	CH- / Page-
VOL	Vol - Receiver	VOL −	Vol -
	Up CD		Up
PLAYLIST /CATEGORY	Left CD		Left
ENTER	Enter CD	OK	OK
PLAYLIST /CATEGORY	Right CD		Right
SETUP	Setup CD	OPT-TOOLS SETUP	Setup / OPT /
	Down CD		Down
RETURN	Return CD	RETURN BACK	Back / Return
AUDIO	Audio CD	LANG I/II AUDIO	Audio / Lang I/II
	I<< CD	PRESET-	I<< / Preset-
	>>I CD	PRESET+	>>I / Preset+
	<< CD	TUNE-	<< / Tune-

Original		Replacement	
	Play CD	SLOW	Play / Slow
	>> CD	TUNE+	>> / Tune+
	Pause CD	STEP-FREEZE	Pause / Step / Freeze
	Stop CD	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search CD	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat CD	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random CD	Prime Video RANDOM	Blue / Prime Video / Random
STEREO PLAY MODE	Play Mode CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9

Original	Replacement	Original	Replacement
+10/ - - / - - 10/ D. Tu Dimmer CD	GUIDE EPG Guide / EPG / -/--		
0/ 11 CD	HDMI - SAT 0 0		
CLR/ Sleep/ 12	PC FAV MARKER Fav / Marker / PC		

Original		Replacement	
ON/STANDBY	Power Receiver Zone 2		Power
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+
VOL	Vol + Zone 2	VOL	Vol +
ALBUM	CH Disc/Album Zone 2	CH PAGE	CH- / Page-
VOL	Vol - Zone 2	VOL	Vol -
	Up Zone 2		Up
PLAYLIST /CATEGORY	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST /CATEGORY	Right Zone 2		Right
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	I<< Zone 2	PRESET-	I<< / Preset-
	>>I Zone 2	PRESET+	>>I / Preset+
	<< Zone 2	TUNE-	<< / Tune-
	Play Zone 2	SLOW	Play / Slow

Original		Replacement	
	>> Zone 2	TUNE+	>> / Tune+
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Stop Zone 2	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music Zone 2	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
STEREO PLAY MODE	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10	+10/--/--10/D.Tu Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement		Original	Replacement
0 / 11	Zone 2	0	0		
CLR / SLEEP / 12	CLR/Sleep/12	FAV MARKER	Fav / Marker / PC		