| Original | Replacement | Original | Replacement |
|---|---|---|---|
| On/Standby | Power | Up | Up |
| Display | Display / Media | Left | Left |
| DVD / BD | Shift + 2 | Enter | OK |
| VCR / DVR | Shift + 4 | Right | Right |
| CBL/SAT | Shift + 0 | Setup | Setup / OPT / |
| Game | Shift + 8 | Down | Down |
| AUX | Shift + 7 | Return | Back / Return |
| TUNER | Shift + 6 | Home/Audio | Menu / Home |
| TV / CD | Shift + 1 | Home/Audio | Audio / Lang I/II |
| TV / CD | Shift + 3 | I << | I << / Preset- |
| PORT | Shift + 5 | >>I | >>I / Preset+ |
| PC | Shift + Fav / Marker / PC | << | << / Tune- |
| Muting | Mute / Dimmer | Play | Play / Slow |
| CH/Disc/Album | CH+ / Page+ | >> | >> / Tune+ |
| Vol + | Vol + | Pause | Pause / Step / Freeze |
| CH/Disc/Album | CH- / Page- | Stop | Stop / Hold |
| Vol - | Vol - | Movie Tv | Red / Netflix / Search |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| MUSIC REPEAT | Music | APP REPEAT | Green / APP / Repeat | CLR SLEEP 12 | CLR/Sleep/12 | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| GAME RANDOM | Game | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | | | |
| THX PLAY MODE | THX | Prime Video RANDOM | Blue / Prime Video / Random | | | | |
| 1 | 1 | TV 1 | 1 | | | | |
| 2 | 2 | DVD 2 | 2 | | | | |
| 3 | 3 | CD-STB 3 | 3 | | | | |
| 4 | 4 | VIDEO 4 | 4 | | | | |
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX-HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| +10 D.TUN DIMMER | +10/--/---10/Dimmer/D.Tun | -/-- GUIDE EPG | Guide / EPG / -/-- | | | | |
| +10 D.TUN DIMMER | +10/--/---10/Dimmer/D.Tun | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer | | | | |
| 0 11 | 0/11 | HDMI-SAT 0 | 0 | | | | |
| CLR SLEEP 12 | CLR/Sleep/12 | PC FAV MARKER | Fav / Marker / PC | | | | |
| CLR SLEEP 12 | CLR/Sleep/12 | TIMER SLEEP | Sleep / Timer | | | | |

| Original | Replacement |
|---|---|
| Power | Power |
| DVD/BD | Shift + 2 |
| VCR / DVR | Shift + 4 |
| CBL/SAT | Shift + 0 |
| Game | Shift + 8 |
| AUX | Shift + 7 |
| TUNER | Shift + 6 |
| TV / CD | Shift + 3 |
| TV / CD | Shift + 1 |
| PORT | Shift + 5 |
| PC | Shift + Fav / Marker / PC |
| Muting Receiver | Mute / Dimmer |
| Vol + Receiver | Vol + |
| Vol - Receiver | Vol - |
| Top Menu | D. Menu / Top |
| Up | Up |
| Menu | Menu / Home |

| Original | Replacement |
|---|---|
| Left | Left |
| Enter | OK |
| Right | Right |
| Setup | Setup / OPT / |
| Down | Down |
| Return | Back / Return |
| Audio | Audio / Lang I/II |
| I << | I << / Preset- |
| >>I | >>I / Preset+ |
| << | << / Tune- |
| Play | Play / Slow |
| >> | >> / Tune+ |
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Search | Red / Netflix / Search |
| Repeat | Green / APP / Repeat |
| Random | Blue / Prime Video / Random |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| THX PLAY MODE | Play Mode | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| 1 | 1 | TV 1 | 1 | | |
| 2 | 2 | DVD 2 | 2 | | |
| 3 | 3 | CD - STB 3 | 3 | | |
| 4 | 4 | VIDEO 4 | 4 | | |
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| +10 D.TUN DIMMER | +10/ - - / - - 10/ D. Tu Dimmer | -/-- GUIDE EPG | Guide / EPG / - / - - | | |
| 0 11 | 0/ 11 | HDMI - SAT 0 | 0 | | |
| CLR SLEEP 12 | CLR/ Sleep/ 12 | PC FAV MARKER | Fav / Marker / PC | | |
| CLR SLEEP 12 | CLR/ Sleep/ 12 | TIMER SLEEP | Sleep / Timer | | |
| CLR SLEEP 12 | CLR/ Sleep/ 12 | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| | | | | | |
| | | | | | |

| Original | Replacement |
|---|---|
| Power | Power |
| DVD / BD | Shift + 2 |
| VCR / DVR | Shift + 4 |
| CBL/SAT | Shift + 0 |
| Game | Shift + 8 |
| AUX | Shift + 7 |
| TUNER | Shift + 6 |
| TV/CD | Shift + 3 |
| TV/CD | Shift + 1 |
| PORT | Shift + 5 |
| PC | Shift + Fav / Marker / PC |
| Muting Receiver | Mute / Dimmer |
| CH/Disc+ | CH+ / Page+ |
| Vol + Receiver | Vol + |
| CH/Disc- | CH- / Page- |
| Vol - Receiver | Vol - |
| Up | Up |

| Original | Replacement |
|---|---|
| Left | Left |
| Enter | OK |
| Right | Right |
| Setup | Setup / OPT / |
| Down | Down |
| Return | Back / Return |
| Audio | Audio / Lang I/II |
| I << | I << / Preset- |
| >>I | >>I / Preset+ |
| << | << / Tune- |
| Play | Play / Slow |
| >> | >> / Tune+ |
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Search | Red / Netflix / Search |
| Repeat | Green / APP / Repeat |
| Random | Blue / Prime Video / Random |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| THX PLAY MODE | Play Mode | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| 1 | 1 | TV 1 | 1 | | |
| 2 | 2 | DVD 2 | 2 | | |
| 3 | 3 | CD - STB 3 | 3 | | |
| 4 | 4 | VIDEO 4 | 4 | | |
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| +10 D.TUN DIMMER | +10/ - - / - - 10/ D. Tu Dimmer | GUIDE EPG | Guide / EPG / - / - - | | |
| 0 | 0/ 11 | HDMI - SAT 0 | 0 | | |
| CLR SLEEP | CLR/ Sleep/ 12 | TIMER SLEEP | Sleep / Timer | | |
| CLR SLEEP | CLR/ Sleep/ 12 | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| CLR SLEEP | CLR/ Sleep/ 12 | PC FAV MARKER | Fav / Marker / PC | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power Receiver | Power | Play | Play / Slow |
| Muting Receiver | Mute / Dimmer | >> | >> / Tune+ |
| CH | CH+ / Page+ | Pause | Pause / Step / Freeze |
| Vol + | Vol + | Stop | Stop / Hold |
| CH Disc/Album | CH- / Page- | Movie TV | Red / Netflix / Search |
| Vol - | Vol - | Music | Green / APP / Repeat |
| Up | Up | Game | Yellow / YouTube / Repeat |
| Left | Left | Stereo | Blue / Prime Video / Random |
| Enter | OK | 1 | 1 |
| Right | Right | 2 | 2 |
| Setup | Setup / OPT / | 3 | 3 |
| Down | Down | 4 | 4 |
| Return | Back / Return | 5 | 5 |
| Audio | Audio / Lang I/II | 6 | 6 |
| I << | I << / Preset- | 7 | 7 |
| >>I | >>I / Preset+ | 8 | 8 |
| << | << / Tune- | 9 | 9 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| +10/ - - / - - 10/ D. Tu Dimmer | Guide / EPG / - / - - | | |
| +10/ - - / - - 10/ D. Tu Dimmer | + Shift + Mute / Dimmer | | |
| 0/ 11 | 0 | | |
| CLR/ Sleep/ 12 | Fav / Marker / PC | | |
| CLR/ Sleep/ 12 | Exit / Cancel / Clear | | |
| CLR/ Sleep/ 12 | Sleep / Timer | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |