Original	Replacement
Power Receiver	Power
BD/DVD	SHIFT + 2
CBL/SAT	SHIFT + 0
Game	SHIFT + 9
PC	SHIFT + FAV MARKER
AUX	SHIFT + 7
TUNER	SHIFT + 6
TV/CD	SHIFT + 3
Phono	SHIFT + 4
NET	SHIFT + GUIDE EPG
USB	SHIFT + 8
Display	DISPLAY
Muting	MUTE
CH/Disc/Album	CH PAGE
Vol +	VOL
CH/Disc/Album	CH PAGE
Vol -	VOL

Original	Replacement
Up	Up
Left Playlist	Left
Enter	OK
Right Playlis	Right
Q/Setup	SETUP
Down	Down
Return	BACK
Home/Audio	AUDIO
I<<	PRESET-
<<	TUNE-
>>	TUNE+
>>I	PRESET+
Pause	STEP-FREEZE
Play	SLOW
Stop	HOLD
Movie/Tv/Search/	NETFLIX
Music/Repeat/B	APP

Original		Replacement		Original	Replacement
RANDOM GAME C	Game/ Random/	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MODE STEREO D	Stereo/ Mode/ D	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
-/--10 +10 D.TUN DIMMER	+10/ - - / - - - 10/ Dimmer/ D. Tun	-/-- GUIDE EPG	Guide / EPG / - / - -		
11 0	0/ 11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		
12 CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original		Replacement	
SOURCE	Power BD/DVD		Power
	Play BD/DVD	SLOW	Play / Slow
	Pause BD/DVD	STEP-FREEZE	Pause / Step / Freeze
	Stop BD/DVD	HOLD	Stop / Hold
	<< BD/DVD	TUNE-	<< / Tune-
	>> BD/DVD	TUNE+	>> / Tune+
	I<< BD/DVD	PRESET-	I<< / Preset-
	>>I BD/DVD	PRESET+	>>I / Preset+
AUDIO HOME	Audio BD/DVD	LANG I/II AUDIO	Audio / Lang I/II
TOP MENU SP/GUIDE	Top Menu	TOP MENU D.MENU	D.Menu / Top
Q SETUP	Setup BD/DVD	OPT-TOOLS SETUP	Setup / OPT /
MENU PREV CH	Menu BD/DVD	HOME MENU	Menu / Home
	Up BD/DVD		Up
PLAYLIST	Left BD/DVD		Left
ENTER	Enter BD/DVD	OK	OK
PLAYLIST	Right BD/DVD		Right
12 CLR SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
	Down BD/DVD		Down
RETURN	Return BD/DVD	RETURN BACK	Back / Return
VOL	Vol + Receiver	+ VOL	Vol +
BD/DVD	BD/DVD	LIST SMART	Smart / List
VOL	Vol - Receiver	VOL –	Vol -
CBL/SAT	CBL/SAT	MEDIA DISPLAY	Display / Media
1	1 BD/DVD	TV 1	1
2	2 BD/DVD	DVD 2	2
3	3 BD/DVD	CD-STB 3	3
4	4 BD/DVD	VIDEO 4	4
5	5 BD/DVD	TAPE 5	5
6	6 BD/DVD	TUNER 6	6
7	7 BD/DVD	AUX-HDD 7	7
8	8 BD/DVD	USB 8	8
9	9 BD/DVD	BLUETOOTH 9	9
10 +10 D.TUN DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
11 0	0/11 BD/DVD	HDMI-SAT 0	0

Original	Replacement
CLR/12 BD/DVD	Fav / Marker / PC
Search BD/DVD	Red / Netflix / Search
Repeat BD/DVD	Green / APP / Repeat
Stereo/Mode	Yellow / YouTube / Repeat
Random	Blue / Prime Video / Random
Power CBL/SAT	Shift + Power
Play CBL/SAT	Shift + Play /
Pause CBL/SAT	Shift + Pause / Step /
Stop CBL/SAT	Shift + Stop /
<< CBL/SAT	Shift + << /
>> CBL/SAT	Shift + >> /
Setup CBL/SAT	Shift + Setup / OPT / Tools
Menu/Prev CH CBL/SAT	Shift + Menu /
Up CBL/SAT	Shift + Up
Left CBL/SAT	Shift + Left
Enter CBL/SAT	Shift + OK
Right CBL/SAT	Shift + Right

Original	Replacement
Down CBL/SAT	Shift + Down
Return CBL/SAT	Shift + Back / Return
CH Disc/Album+ CBL/SAT	Shift + CH+ /
CH Disc/Album- CBL/SAT	Shift + CH- /
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9
Guide CBL/SAT	Shift + Guide / EPG / -/--
0/11 CBL/SAT	Shift + 0
Movie Tv/Search CBL/SAT	Shift + Red / Netflix /
Music/Repeat CBL/SAT	Shift + Green / APP / Repeat

Original		Replacement		Original	Replacement
RANDOM GAME C	Game/ Random	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
MODE STEREO D	Stereo/ Mode	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		

Original		Replacement	
SOURCE	Power CD		Power
	Play CD	SLOW	Play / Slow
	Pause CD	STEP-FREEZE	Pause / Step / Freeze
	Stop CD	HOLD	Stop / Hold
	<< CD	TUNE-	<< / Tune-
	>> CD	TUNE+	>> / Tune+
	I<< CD	PRESET-	I<< / Preset-
	>>I CD	PRESET+	>>I / Preset+
AUDIO HOME	Audio CD	LANG I/II AUDIO	Audio / Lang I/II
Q SETUP	Setup CD	OPT-TOOLS SETUP	Setup / OPT /
	Up CD		Up
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	OK
PLAYLIST	Right CD		Right
	Down CD		Down
RETURN	Return CD	RETURN BACK	Back / Return
VOL	Vol + Receiver	VOL	Vol +

Original		Replacement	
TV/CD	TV/CD	LIST SMART	Smart / List
CH DISC	CH/Disc+ CD	CH PAGE	CH+ / Page+
VOL	Vol - Receiver	VOL	Vol -
ALBUM	CH/Disc- CD	CH PAGE	CH- / Page-
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	-/-- GUIDE EPG	Guide / EPG / -/--
11 0	0/11 CD	HDMI-SAT 0	0
12 CLR SLEEP	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC
SEARCH MOVIE/TV A	Search CD	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
REPEAT MUSIC B — Repeat CD	APP REPEAT — Green / APP / Repeat		
MODE STEREO D — Mode CD	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
RANDOM GAME C — Random CD	Prime Video RANDOM — Blue / Prime Video / Random		

Original		Replacement	
RECEIVER	Power Receiver Zone 2		Power
CH DISC +	CH Disc/Album+ Zone 2	CH + PAGE	CH+ / Page+
VOL	Vol + Zone 2	+ VOL	Vol +
ALBUM	CH Disc/Album Zone 2	CH PAGE −	CH- / Page-
VOL	Vol - Zone 2	VOL −	Vol -
	Up Zone 2		Up
PLAYLIST	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST	Right Zone 2		Right
Q SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO HOME	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	I<< Zone 2	PRESET-	I<< / Preset-
	>>I Zone 2	PRESET+	>>I / Preset+
	<< Zone 2	TUNE-	<< / Tune-
	Play Zone 2	SLOW	Play / Slow

Original		Replacement	
	>> Zone 2	TUNE+	>> / Tune+
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Stop Zone 2	HOLD	Stop / Hold
SEARCH MOVIE/TV A	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC B	Music Zone 2	APP REPEAT	Green / APP / Repeat
RANDOM GAME C	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MODE STEREO D	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10/--/--10/D.Tun Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement		Original	Replacement
11 0	0/11 Zone 2	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC		