Original	Replacement
On / Standby	Power
Input Selector V1	1
Input Selector V2	4
Input Selector V3	7
Input Selector Multi CH	8
Input Selector	2
Input Selector	5
Input Selector Tuner	6
Input Selector CD	3
Dimmer	Shift + Mute / Dimmer
Sleep	Sleep / Timer
Power Tv	Shift + Power
Vol + Tv	Shift + Vol +
CH/Disc/Album	CH+ / Page+
Vol +	Vol +
Input Tv	Shift + AV / Input / RDS
Vol - Tv	Shift + Vol -

Original	Replacement
CH/Disc/Album	CH- / Page-
Vol -	Vol -
Guide/Top	Guide / EPG / -/--
Guide/Top	D. Menu / Top
Up	Up
Muting	Mute / Dimmer
Left	Left
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Setup	Setup / OPT /
Pause	Pause / Step / Freeze
Play	Play / Slow
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+

Original	Replacement	Original	Replacement
I <<	PRESET- I << / Preset-		
>>I	PRESET+ >>I / Preset+		
Listening Mode Stereo	EQ SUBTITLE Subtitle / EQ		
Listening Mode Surround	SURROUND Eject / Surround		
Listening Mode <	TITLE SOUND Sound / Title		
Listening Mode >	LANG I/II AUDIO Audio / Lang I/II		
Test Tone	NETFLIX SEARCH Red / Netflix / Search		
CH Sel	APP REPEAT Green / APP / Repeat		
Level -	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Level +	Prime Video RANDOM Blue / Prime Video / Random		
Display	MEDIA DISPLAY Display / Media		
L. Night	SIZE ZOOM Zoom / Size		
Cine FLTR	FORMAT PICTURE Picture / Format		

Original		Replacement	
STANDBY/ON	Power		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10 10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 11 DIMMER	0/11	HDMI-SAT 0	0
CLR 12 SLEEP	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
PLAYLIST	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST	Right/Playlist/C		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
LISTENING SURROUND	Surround	SHIFT + SURROUND	Shift + Eject / Surround
G MODE	< Listening Mode	SHIFT + TITLE SOUND	Shift + Sound / Title
	Listening Mode >	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II

Original		Replacement		Original	Replacement
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ		
RANDOM / LEVEL-	Random	Prime Video / RANDOM	Blue / Prime Video / Random		
REPEAT / LEVEL+	Repeat	APP / REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
PLAY MODE / VCR	VCR	SHIFT + VIDEO 4	Shift + 4		
PLAY MODE / VCR	Play Mode VCR	FORMAT / PICTURE	Picture / Format		
L NIGHT / DVD	DVD	SHIFT + DVD 2	Shift + 2		
CINE FLTR / HDD	HDD	SHIFT + AUX - HDD 7	Shift + 7		

Original		Replacement	
STANDBY/ON	On / Standby		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR SLEEP	12	PC FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH PAGE +	CH+ / Page+
VOL ▲	Vol +	VOL +	Vol +
CH DISC ALBUM −	Disc-	CH PAGE −	CH- / Page-
VOL ▼	Vol -	VOL −	Vol -

Original		Replacement	
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
►	Play	SLOW ►	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
LISTENING SURROUND	Surround	SURROUND ⏏	Eject / Surround
G MODE ◄	< Listening Mode	TITLE SOUND	Sound / Title
►	Listening Mode >	LANG I/II AUDIO	Audio / Lang I/II
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
STANDBY/ON	Power		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CH DISC	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
LISTENING SURROUND	Surround	SURROUND	Eject / Surround
G MODE	< Listening Mode	TITLE SOUND	Sound / Title
	Listening Mode >	LANG I/II AUDIO	Audio / Lang I/II
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L.NIGHT DVD	L.Night	TIMER SLEEP	Sleep / Timer