Original		Replacement	
Power	Power	Power	Power
Eject iPod	Eject iPod	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Eject CD	Eject CD	SURROUND	Eject / Surround
Sleep	Sleep	TIMER SLEEP	Sleep / Timer
PLAY	Timer/Play	SIZE ZOOM	Zoom / Size
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
+ VOL	Vol +	+ VOL	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
VOL –	Vol -	VOL –	Vol -
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
DEL	Del	RETURN BACK	Back / Return
0	0	HDMI-SAT 0	0
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PLAY MODE	Play Mode	LIST SMART	Smart / List
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
CD▶/II	Play/Pause CD	SLOW ▶	Play / Slow
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
⏮/◀◀	<<|<<	TUNE- ◀◀	<< / Tune-
iPod▶/II	Play/Pause iPo	STEP-FREEZE II	Pause / Step / Freeze
▶▶/⏭	>>|>>|	TUNE+ ▶▶	>> / Tune+
RE-MASTER	Re-Master	TOP MENU D.MENU	D.Menu / Top
■	Stop	HOLD ■	Stop / Hold
D.BASS	D.Bass	LANG I/II AUDIO	Audio / Lang I/II
iPod MENU	iPod Menu	HOME MENU	Menu / Home

Original	Replacement	Original	Replacement
PRESET EQ Preset EQ	EQ SUBTITLE Subtitle / EQ		
Up	Up		
BASS/TREBLE Bass/Treble	TITLE SOUND Sound / Title		
Left	Left		
OK OK	OK OK		
Right	Right		
DISPLAY -DIMMER Display/Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer		
DISPLAY -DIMMER Display/Dimmer	MEDIA DISPLAY Display / Media		
Down	Down		
SURROUND Surround	SHIFT + SURROUND Shift + Eject / Surround		
AUTO OFF Auto Off	SHIFT + Shift + Power		
TUNE MODE Tune Mode	GOTO TEXT Text / Goto		
FM MODE FM Mode	OPT-TOOLS SETUP Setup / OPT /		
INPUT LEVEL Input Level	RDS AV INPUT AV / Input / RDS		