| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Recall/Last View | | Pre Ch |
| | Radio/Tv | | TV/R |
| | CH/Page+ | | Ch + |
| | CH/Page- | | Ch - |
| | Internet | | Smart |
| | Skype | | Media |

| Original | | Replacement | |
|---|---|---|---|
| | I<< Skip | | I<< |
| | Skip >>I | | >>I |
| | << Slow/Search | | << |
| | Slow/Search >> | | >> |
| | Stop | | Stop |
| | Pause | | Pause |
| | Play | | Play |
| | i/Status | | Info |
| | X/Exit | | Exit |
| | Option | | Options |
| | Return | | Back |
| | Direct Navigator | | List |
| | Guide | | Guide |
| | Function Menu | | Menu |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | | Replacement | |
|---|---|---|---|
| | Left | | Left |
| OK | OK | OK | Ok |
| | Red | A | Red |
| | Green | B | Green |
| | Yellow | C | Yellow |
| | Blue | D | Blue |
| REC | Rec | REC MODE | Rec |
| REC MODE | Rec Mode | SHIFT + REC MODE | Shift + Rec |
| TEXT | Text | REPEAT TEXT | Text |
| STTL | STTL | AD SUBT | Subt |
| PROG/CHECK | Prog/Check | PROG SLEEP | Sleep |
| CHAPTER | Chapter | TIMER AV | AV |
| TIME SLIP | Time Slip | ZOOM | Eject |
| AUDIO | Audio | SOUND DUAL | Dual |
| DRIVE SELECT | Drive Select | E-MANUAL D.MENU | D. Menu |
| DEL | Del | SHIFT + CLEAR EXIT | Shift + Exit |
| MANUAL -10s | Manual Skip -10s | PICTURE FORMAT | Format |

| Original | | Replacement | |
|---|---|---|---|
| MANUAL SKIP +60s | Manual Skip +60s | ECO 3D | 3D |
| TV | Power Tv | SHIFT + | Shift + Power |
| INPUT AV | Av Input Tv | SHIFT + TIMER AV | Shift + AV |
| VOL + | Vol+ Tv | VOL + | Vol + |
| VOL | Vol- Tv | VOL − | Vol - |
| CH | CH+ Tv | SHIFT + CH + | Shift + Ch + |
| CH | CH- Tv | SHIFT + CH − | Shift + Ch - |