| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Last View | | Pre Ch |
| | Radio/Tv | | TV/R |
| | Internet | | Smart |
| | Netflix | | Media |
| | Rec | | Rec |
| | Prog/Check | | Sleep |

| Original | | Replacement | |
|---|---|---|---|
| | Play | | Play |
| | >> | | >> |
| | << | | << |
| | Pause | | Pause |
| | >>I | | >>I |
| | I<< | | I<< |
| | Stop | | Stop |
| | Exit | | Exit |
| | i/Status | | Info |
| | Return | | Back |
| | Guide | | Guide |
| | Function Menu | | Menu |
| | Video Menu | | D. Menu |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |

| Original | | Replacement | |
|---|---|---|---|
| OK | OK | OK | Ok |
| OPTION | Option | SETTINGS OPT | Options |
| | Red | A | Red |
| | Green | B | Green |
| | Yellow | C | Yellow |
| | Blue | D | Blue |
| AUDIO | Audio | SOUND DUAL | Dual |
| DRIVE SELECT | Drive Select | DISC NAV LIST | List |
| TEXT | Text | REPEAT TEXT | Text |
| STTL | STTL | AD SUBT | Subt |
| +60s | +60s | ECO 3D | 3D |
| -10s | -10s | PICTURE FORMAT | Format |
| PAGE CH | Page/CH+ | + CH | Ch + |
| CH | Page/CH- | CH − | Ch - |
| + VOL | Tv Vol+ | + VOL | Vol + |
| VOL | Tv Vol- | VOL − | Vol - |
| INPUT AV | AV Input Tv | TIMER AV | AV |

| Original | | Replacement | |
|---|---|---|---|
| CH | CH+ Tv | SHIFT + + CH | Shift + Ch + |
| CH | CH- Tv | SHIFT + CH − | Shift + Ch - |
| | Power Tv | SHIFT + | Shift + Power |