Original	Replacement	Original	Replacement
Power	Power	Mute	MUTE
Play	Play		
Pause	Pause		
I <<	First		
>>I	Last		
Stop	Stop		
)(	EXIT		
Back	BACK		
Album/Preset	CH +		
Album/Preset	CH -		
Vol +	VOL +		
Vol -	VOL -		
Display	INFO		
Prog	MENU		
Sleep/Timer	VOD		
Clock/Scan	-/-- / EPG		
Sound	Audio		

Original		Replacement	
	Power		Power
	Play		Play
	Pause		Pause
	>>I		Last
	I <<		First
	Stop		Stop
	)(	EXIT	EXIT
	Back	BACK	BACK
+	Vol +	+ VOL	VOL +
–	Vol -	VOL –	VOL -
SOUND	Sound		Audio
ALBUM/ PRESET	Album/Preset	+ CH	CH +
ALBUM/ PRESET	Album/Preset	CH –	CH -
	Mute		MUTE
DISPLAY	Display	INFO	INFO
SLEEP TIMER	Sleep/Timer	VOD	VOD
CLOCK SCAN	Clock/Scan	EPG 1. -/--	-/-- / EPG

Original		Replacement	
PROG	Prog	MENU	MENU

Original	Replacement	Original	Replacement
Power	Power	Clock/Scan	-/-- / EPG
Play	Play		
Pause	Pause		
>>I	Last		
I <<	First		
Stop	Stop		
)(	EXIT		
Back	BACK		
Album/Preset	CH +		
Album/Preset	CH -		
Vol +	VOL +		
Vol -	VOL -		
Sound	Audio		
Mute	MUTE		
Display	INFO		
Prog	MENU		
Sleep/Timer	VOD		

Original	Replacement
Power	Power
Play	Play
Pause	Pause
I <<	First
>>I	Last
Stop	Stop
)(	EXIT
Back	BACK
Vol +	VOL +
Vol -	VOL -
Sound	Audio
Mute	MUTE
Album/Preset	CH +
Album/Preset	CH -
Display	INFO
Prog	MENU
Sleep/Timer	VOD

Original	Replacement
Clock/Scan	-/-- / EPG