Original	Replacement	Original	Replacement
Power	Power	>>I	>>I
Mute	Mute	>>I	Right
Sleep/Timer	Smart	I <<	I <<
Clock/Display	3D	I <<	Left
RDS/Info	Info		
Menu	Menu		
Prog	Sleep		
DBB	Exit		
Play/Pause	Play		
Stop	Stop		
Vol +	Vol +		
Vol -	Vol -		
Repeat	Text		
Shuffle	Ch -		
OK	Ok		
Up	Up		
Down	Down		

Original		Replacement	
MUTE	Mute	MUTE	Mute
▶II	Play/Pause	PLAY MODE ▶	Play
⏻	Power	⏻	Power
OK	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
⏭	>>I	⏭	>>I
⏭	>>I	▶	Right
⏮	I <<	⏮	I <<
⏮	I <<	◀	Left
PROG	Prog	PROG SLEEP	Sleep
■	Stop	■	Stop
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	CH –	Ch -
SCAN	Scan	RETURN BACK	Back

Original		Replacement	
TIMER SLEEP	Sleep/Timer	HOME SMART	Smart
DISPLAY CLOCK	Clock/Display	ECO 3D	3D
INFO. RDS	RDS/Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
DBB	DBB	CLEAR EXIT	Exit

Original	Replacement	Original	Replacement
Power	Power	>>I	Right
Mute	Mute	I <<	I <<
Sleep/Timer	Smart	I <<	Left
Clock/Display	3D		
RDS/Info	Info		
Menu	Menu		
DBB	Exit		
Scan	Back		
Prog	Sleep		
Stop	Stop		
Vol +	Vol +		
Vol -	Vol -		
Repeat	Text		
OK	Ok		
Down	Down		
Up	Up		
>>I	>>I		

Original	Replacement	Original	Replacement
Power	Power		
Mut e	Mut e		
Sl eep/ Ti mer	Smar t		
Cl ock/ Di spl ay	3D		
RDS/ I nf o	I nf o		
DBB	Exi t		
St op	St op		
Vol +	Vol +		
Vol -	Vol -		